


6616 SIXTEEN ZONE AND 6632 THIRTY-TWO ZONE FIRE ALARM CONTROL PANELS



OPERATION AND INSTALLATION MANUAL

TABLE OF CONTENTS

Section	Title	Page
1.0	DESCRIPTION	2
	1.1 Standard panel features	2
	1.2 Additional panel features	2
	1.3 Field Selectable features	2
	1.4 Optional equipment	2
	1.5 Call functions	2
	1.6 Control panel assembly	3
2.0	INSTALLATION	3
	2.1 Unpacking and inspection	3
	2.2 Mounting	3
	2.3 Install kit procedure	4
3.0	INSTALLATION WIRING	4
	3.1 Module placement	4
	3.2 Alarm receiving module (class B)	4
	3.3 Circuit testing procedure	5
	3.4 Supervisory receiving module	5
	3.5 Alarm/supervisory receiving module	5
	3.6 Alarm receiving module (class A)	6
	3.7 Alarm output module	6
	3.8 Auxiliary alarm relay module	7
	3.9 NO programming module	7
	3.10 Fire department module	8
	3.11 Auxiliary power module	8
	3.12 Annunciator driver module	8
	3.13 Expanded feature module	10
	3.14 Field selectable features	11
	3.15 Primary, secondary and system power	11
4.0	SYSTEM CHECK OUT PROCEDURES	12
	4.1 General information	12
	4.2 Preliminary test	12
	4.3 Indiscover	12
	4.4 Installation verification	13
	4.5 Alarm test	13
	4.6 Decade address	13
	4.7 Open circuit test	14
	4.8 Battery power test	14
	4.9 Battery supervision test	14
5.0	OPERATIONS	14
	5.1 Functions of control switches and indicators	14
	5.2 Silent test switch	14
	5.3 Drill switch	15
	5.4 Auxiliary disconnect switch	15
	5.5 Alarm w/flasher	15
	5.6 Individual zone disconnect	15
	5.7 A.C. power on LED	16
	5.8 Alarm zone LED	16
	5.9 Alarm silenced LED	16
	5.10 Zone fault LED	16
	5.11 Ground fault (FD)	16
	5.12 Battery fault (FD)	16
	5.13 Silent test LED	16
	5.14 Auxiliary disconnect LED	16
	5.15 Open door trouble LED	16
6.0	OPERATION MODES	16
	6.1 General information	16
	6.2 Supervisory mode	16
	6.3 Alarm	16
	6.4 Responding to an alarm	16
	6.5 Trouble	16
	6.6 Responding to a trouble	17
7.0	REHABILITATION, IN OPERATIONAL TEST OR DRIFT	17
	7.1 General information	17
	7.2 Silencing a test or drill	17
	BATTERY SELECTION CHART APPENDIX A	18
	CUSTOMER DRAWINGS APPENDIX B	20

1.0 DESCRIPTION

The Edwards Catalogue #6616 Fire Alarm Control Panel is a 24VDC supervised panel that provides plug in modules for Alarm Inputs (up to 16), Alarm Outputs, Ancillary and Auxiliary Control Circuits and I/O programming for single stage system applications. The modular design plus field selectable options allows on site customizing of the system for specified operating configurations. The Catalogue #6632 Fire Alarm Control Panel may be configured with up to 32 Input Circuits. The panel is UL listed and meets all performance and operational requirements of UL 164 and NFPA 72A.

1.1 STANDARD PANEL FEATURES

(See Figure 1)

- (1) Power on LED
- (2) Common alarm LED
- (3) Alarm silenced LED
- (4) Zone alarm LED
- (5) Ground fault LED
- (6) Battery fault LED
- (7) Silent alarm test switch and indicator
- (8) Drill and Ancillary disconnect switch
- (9) Smart Switch and Operator prompt LED's for:
 - (9.1) System reset
 - (9.2) Alarm signal silence
 - (9.3) Trouble signal silence
- (10) Common trouble LED and signal
- (11) Individual zone alarm and service trouble LED's

See Section 5 for Description and Function of each feature.




FIG. 1

1.2 ADDITIONAL PANEL FEATURES

- (available on 6616-B904)
 - Installation Verification
 - Alarm Verification
 - Individual Zone Bypass

1.3 FIELD SELECTABLE FEATURES

- One minute manual signal silence and rest inhibit.
- Continuous, 120 ppm or 3-5-5 signal rate.
- Two to thirty minute automatic signal silence.
- Alarm output module selectable for Class A or B configuration.
- Continuous alarm output may be selected for silence by system reset only.

1.4 OPTIONAL EQUIPMENT

- 6616-B351 Alarm Receiving module Class B
- 6616-B352 Supervisory Rec. module
- 6616-B353 Alarm/Sup. Rec. module
- 6616-B354 Alarm Receiving module Class A
- 6616-B355 Alarm Output module
- 6616-B321 Ancillary Relay module
- 6616-B331 I/O Programming module
- 6616-B402 Annunciator Driver module
- 6616-B403 Expanded Features module
- 6616-B711 Remote Station module
- 6616-B712 Municipal Tie module
- 6616-B713 Reverse Polarity module
- 6616-B714 Auxiliary Power module
- 6616-B801 16 LED Annunciator c/w features
- 6616-B802 16 LED Annunciator less features
- 6632-A601 Flush trim for 7516
- 6632-A601 Flush trim for 7532
- 8556-B110 Remote Trouble Unit

1.5 CONFIGURATIONS

1.5.1 The panel packaging for the Catalogue #6616 Fire Alarm Control Panel consists of three cartons, one for each of the following:

- 6616-B901 Cabinet Assembly
- 6616-B902/B904 Common Control Bin Assembly and Power Supply
- One Standby Battery
- See Drawing 46000-0781 in Appendix B

1.5.2 The Catalogue #6632 panel consists of five cartons, one for each of the following:

- 6632-3901 Cabinet Assembly
- 6616-3902/B904 Common Control Bin Assembly and Power Supply
- 6632-3903/3904 Expander Control Bin Assembly and Power Supply

1.6 COMMON CONTROL ASSEMBLY

1.6.1 Either Common Control Bin Assembly includes a bin complete with a Common Control Module and space for eight additional modules. The hinged cover includes the associated system control indicators, switches and 16 zone alarm indicators.

1.6.2 The Expander Bin Assembly includes space for nine additional modules. The hinged cover includes 10 zone alarm indicators.

2.0 INSTALLATION

2.1 UNPACKING AND INSPECTION

Carefully inspect all items for possible damage incurred in shipment. If damage is found immediately notify the local shipping company representative. Be sure that all installation instructions are not discarded along with packaging materials.

2.2 MOUNTING



Unpack the wallbox and door. Store the door in a safe place to prevent damage prior to assembly. Proceed to mount the wallbox as described below (Refer to Figure 2 for 6610 detail or Figure 2A for 6632 detail).

2.2.1 Remove required knockouts for conduit entrance.

2.2.2 FOR SURFACE MOUNTING. Mark the four mounting hole positions per dimensions A and B shown in Figure 2 or 2A. Mount panel to surface using suitable fasteners.

2.2.3 FOR FLUSH MOUNTING USE FLUSH TRIM. (See Figure 2 or 2A).

Note back box outer dimensions C and D to plan required wall cut out. Also note dimension for required installation depth. Mark four mounting hole positions per dimensions A and B. Install panel in wall, and secure using suitable fasteners. Install flush trim to wallbox with screws provided.



2.9 INSTALLATION PROCEDURE

CAUTION
DO NOT CONNECT AC POWER OR BATTERY
TO THE PANEL UNTIL INDICATED BY THIS MANUAL.

See Drawings D48000-0779 or 0750 in Appendix B.

2.9.1 Install the Common Control Bin Assembly on the studs provided using four #8 nuts and washers. The 6632 requires the Common Control and Expander Bin Assemblies.

2.9.2 Install the Power Supply in the bottom of the wallbox for a 0316 configuration. Secure using a #8 nut and washer on the stud provided. The 6632 requires two power supplies to be mounted on the back of the wallbox using two #8 nuts and washers.

2.9.3 Install the additional and/or optional modules into the bin assembly(ies).

Note: These modules should be configured prior to installation. Refer to respective module installation drawing or section 3.0 prior to installing the modules.

2.9.4 Install the battery in the bottom of the wallbox after all installation wiring is complete. Do not connect battery leads to battery at this time.

2.9.6 Hinge plates are packed with the bin assembly for mounting of the door to the surface wallbox or flush trim.

3.0 INSTALLATION WIRING

All Fire Alarm System Components must be installed in accordance with the latest issues of UL 804, NFPA Standards 72A, 72B and 72C and the National Electrical Code. Parallel branching from a circuit is not permitted. When splicing of wires is required, connections must be made in a junction box.

All wiring must be tested for opens, shorts and grounds using an ohmmeter. Any fault must be corrected before making connections to any plug-in module located in the Common Control or Expander Bin Assembly.

3.1 MODULE PLACEMENT

The zero ohm resistor (beige with a black ring) located adjacent to each socket on the printed circuit board in each bin assembly must be removed prior to inserting additional and/or optional modules. See Chart A for module placement.

Note: Never insert a module with the Power On.

3.2 ALARM RECEIVING MODULE (Class B)

Catalogue 6618-3351 Alarm Receiving Modules provide four alarm initiating circuits configured for Class B operation.

Normally open devices, such as manual fire alarm stations, automatic heat detectors and water flow switches can be connected to the initiating circuits in the quantities required.

Up to 60 Edwards approved Two Wire Ionization Smoke Detectors or 30 Two Wire Photoelectric Smoke Detectors may be connected. (ie 0420B, 0250B Ionization; 0269B, 0270B Photoelectric). If detectors with relay bases are required, one detector with a relay base should be the only device installed on the circuit, to ensure the activation of the base relay.

0618-3351 modules may be inserted into either Bin Assembly as indicated in Chart A.

Install wiring as shown in Figure 3. Also install the Edwards UL Listed 049 ohm, 1/2 watt, end of line resistor (P088480-0068 supplied in parts bag) beyond the last initiating device on the circuit. Test the circuit for opens, grounds and shorts using an ohmmeter as shown in Figure 3.




FIG. 3

3.3 CIRCUIT TESTING PROCEDURE

1. With the positive lead (+) of the ohmmeter connected to wire (A) and the negative connected to wire (B) the measurement obtained should be 3K9 ohms. The value of the end of line resistor.

2. Reversing the ohmmeter leads should result in the same measurement.

Note: a) if a short circuit is present a resistance of zero ohms will be indicated.

b) if an open circuit is present an infinite resistance value will be indicated.

3. Measure the resistance between ground and (A) and ground and (B). An infinite resistance should be measured in each case.

4. When testing is complete, connect the wiring to terminals as indicated in Figure 3.

Detailed circuit operation and wire run charts are provided on Drawing C46000-1075 supplied with the module and in Appendix B.

3.4 SUPERVISORY RECEIVING MODULE

Catalogue 6616-B352 Supervisory Receiving Modules provide four supervisory receiving circuits configured for Class B operation.

Each circuit may be configured for N.O. or N.C. initiating devices and for latching or non latching operation. For N.O. Devices, each circuit may be selected for open and short supervision or open supervision only. The maximum number of devices is limited to five if open and short supervision is required and ten for N.C. device operation. Each module is factory set for N.O. Devices with open circuit supervision and latching operation. Check to ensure each module is configured for the proper operation before connecting field wiring.

Test the circuits for opens, grounds and shorts as indicated in 3.2. When testing is complete, connect the wiring to the terminals as indicated in Figure 4.

6616-B352 modules may be inserted into either Bln. Assembly as indicated in Chart A.

Detailed circuit operation, jumper selection and wire run charts are provided on Drawing C46000-1073 supplied with the module and in Appendix B.




FIG. 4

3.5 ALARM/SUPERVISORY RECEIVING MODULE

Catalogue 6616-B353 Alarm/Supervisory Receiving Modules provide two Class B Alarm receiving and two Class B supervisory receiving circuits. Circuits 1 and 2 are configured for Alarm receiving and circuits 3 and 4 are Supervisory receiving. Refer to Section 3.2 and 3.4 for alarm and supervisory circuit specifications.

Test the circuits for opens, grounds and shorts as described in 3.3. When testing is complete connect the wiring to the terminals as indicated in Figure 5.

6616-B353 modules may be inserted into either Bln. Assembly as indicated in Chart A.

Detailed circuit operation, jumper selection and wire run charts are provided on Drawing C46000-1071 supplied with the module and in Appendix B.

ALARM/SUPV. RECEIVING CIRCUIT




FIG. 5

3.6 ALARM RECEIVING MODULE (Class A)

Catalogue #6816-0354 Alarm Receiving Module provides four alarm initiating circuits configured for Class A operation.

Normally open devices, such as manual fire alarm stations, automatic heat detectors and water flow switches can be connected to the initiating circuits in the quantities required.

Up to 50 Edwards approved Two Wire Ionization Smoke Detectors or 30 Two Wire Photoelectric Smoke Detectors may be connected as described in 3.2.

Install the wiring as shown in Figure 6. Test the circuits for opens, grounds and shorts using an ohmmeter as described in 3.3.

6816-0354 modules may be inserted into either B or Assembly as indicated in Chart A. Detailed circuit operation, and wire run charts are provided on Drawing G46000-1077 supplied with the module and in Appendix 2.




FIG. 6

3.7 ALARM OUTPUT MODULE

The Catalogue 6816-0311 Alarm Output Module provides two Class B or one Class A 24VDC signalling circuits. All signalling devices must be polarized and connected in parallel to the circuit. The maximum signal load for the circuit is 2.0 Amps.

Install wiring as shown in Figure 7A. For Class B, install the 3K9 ohm 1/2 watt, end of line resistor (supplied in parts bag) beyond the last signalling device on the circuit as shown. For Class A, wires from the last signalling device on the circuit must be returned to the control panel.

The operation of the 6816-0311 Alarm Output Module is preset at the factory for Class B operation, Alarm Output controlled by Alarm Silence, and Alarm Output common.

To set the module for Class A operation, remove fuses F1 and F2 and replace one fuse in the F3 position and place the four pin plug in position A as shown in Figure 7.



To set the module for silence by system Fuses, position jumper J2 as shown in Figure 7.

To allow the module to be programmed through the PC Programming module, remove jumper J1 as shown in Figure 7.

Test the circuit for opens, grounds and shorts using an ohmmeter as shown in Figure 7A.

1. With the positive (+) of the ohmmeter connected to wire (A) and the negative (-) of the ohmmeter connected to wire (B) the measurement should be approximately zero ohms.
2. Reversing the ohmmeter leads will result in a 3K9 ohms measurement which is the value of the end of line resistor.

3. Measure the resistance between ground and (A); and ground and (B). An infinite resistance should be measured in each case.
4. When tests are complete, connect the wiring to terminals as shown in Figure 7A. Observe polarity indicated.



6616-B311 modules may be inserted into either Bin Assembly as indicated in Chart A. Detailed circuit operation and wire run charts are provided on Drawing 646000-6773 supplied with the module and in Appendix B.


3.8 ANCHILLARY ALARM RELAY MODULE

The Catalogue 6610-B321 Ancillary Alarm Relay Module provides four relays. Each relay provides a form C contact. The contacts transfer when any alarm zone becomes active, and they store when the system is reset. The transfer of contacts may be inhibited by the Ancillary Disconnect switch. The contacts are rated at 5.0 Amp resistive/2.5 Amp inductive at 25VDC/120VAC.

Connect wiring to terminals as shown in Figure 8.

6610-B321 modules may be inserted into either Bin Assembly as indicated in Chart A.

Detailed circuit operation is shown on Drawing 646000-6774 supplied with the module and in Appendix B.



3.9 I/O PROGRAMMING MODULE

The Catalogue 6616-B921 I/O Programming Module provides a 16 X 7 Diode Pin matrix and 4 programmable relays. The matrix inputs are labelled 1 thru 16 for each receiving circuit and outputs 1, 2, 3, 4, 5, 8 and 9 for the individual module locations. See Figure 9.

These 7 outputs provide two system programming functions:

1) Signal Programming - Cal#6616-B311

Alarm Output modules may be programmed to any input circuit by removing jumper J1 on the module, placing the module into an appropriate module location and inserting diode pins into the corresponding sockets in the matrix.

2) Relay Programming - The seven matrix outputs are connected to seven Relay Program-

ming Pins on the module labelled 1,2,3,4,5,8 and 9. The 4 on-board relays are connected to four Relay Pins labelled K1,K2,K3 and K4. Relays are programmed to one or more of the 7 outputs by installing a wire jumper across the appropriate pins.




FIG. 8

Only the 6616-6311 Alarm Output modules have the option of being programmed, by removing jumper J1 on the module. (See 3.7). No other modules will be affected by a matrix output.

A matrix output can only be programmed to a signal module, not a signal circuit. For example, if two individually programmed signal circuits are required, two 6616-6311 Alarm Output modules are required. The individual circuits on each module will be programmed the same.

When configuring a 6632 Control Panel, one matrix may be required per bin. The matrix in the common control bin can only accommodate inputs from zones 1 through 16. A matrix in the expander bin, would accommodate the remaining zones, 17 through 32. The matrix module can be inserted into module location 6 or 7 of each bin.

Each programmable relay provides a form C contact. These contacts transfer when their correlated input(s) become active, and restores when the system is reset. The transfer of contacts may be inhibited by the Auxiliary Disconnect switch. The contacts are rated at 5.0 Amp resistive/120VAC.

PROGRAMMABLE RELAY TERMINALS




FIG. 9A

Connect wiring to terminals as shown in Figure 9A.

Note: in the Installation Verification Mode, the alarm contacts of this module will transfer. The activation of the Auxiliary Disconnect switch before a System Verification is recommended.

6616-6311 modules may be inserted into module location 6 & 7 of either bin, as indicated in Chart A.

Detailed circuit operation is shown on Drawing D46009-0615 supplied with the module and in Appendix B.

3.10 FIRE DEPARTMENT MODULES

3.10.1 REMOTE STATION MODULE

(w/ 24VDC Auxiliary Power)

The Catalogue #6616-6711 Remote Station Module provides 1 set of "C" Alarm contacts, 1 set of "C" Trouble contacts, a Remote Station connection and two 24 VDC sources. (See 3.11 for 24VDC Auxiliary Power description.) Contacts are rated at 5.0 Amp resistive/2.5 Amp inductive at 28VDC/120VAC.

Under normal supervisory conditions, a current limited to 2.5mA is supplied from output terminals 1 and 2. An alarm on the fire alarm system will cause the alarm contacts to transfer and the output current to increase to a maximum of 250mA sending an alarm to the Remote Station. A trouble on the system will cause the trouble contacts to transfer and send a trouble signal to the Remote Station if connected accordingly.

The transmission of an alarm may be inhibited by the Auxiliary Disconnect switch located on the Common Control Bin Assembly cover.

The 6616-B711 may be installed in either Bin Assembly as indicated in Chart A. Connect the field wiring to the terminals as shown in Figure 10.

Detailed circuit operation is shown on Drawing C46000-0777 supplied with the module and in Appendix B.

REMOTE STATION MODULE




FIG. 10

The transmission of an alarm may be inhibited by the Ancillary Disconnect switch located on the Common Control Bin Assembly cover.

The 6616-B712 may be installed in either Bin Assembly as indicated in Chart A. Connect field wiring to the terminals as shown in Figure 10A.

Detailed circuit operation is shown on Drawing C46000-0832 supplied with the module and in Appendix B.

MUNICIPAL TIE MODULE

RELAYS SHOWN WITH THE SYSTEM IN THE NORMAL SUPERVISORY MODE. TRIP COIL RELAY ENERGIZED.




FIG. 10A

3.10.2 MUNICIPAL TIE MODULE

(w/ 24VDC Auxiliary Power)

The Catalogue #6616-B712 Municipal Tie Module provides 1 set of "C" Alarm contacts, 1 set of "C" Trouble contacts, a Municipal Box connection and two 24VDC sources. (See 3.11 for 24VDC Auxiliary Power description.) Contacts are rated at 5.0 Amp resistive/2.5 Amp inductive at 28VDC/120VAC.

An alarm on the fire alarm system will cause the alarm contacts on this module to transfer. This will send an alarm signal to the Municipal Box, causing it to send its code to the Fire Hall or Remote Station.

The red Remote Station operated LED will light when the Municipal Box has operated. When the fire alarm system is being reset, also reset the Municipal Box. The Remote Station operated LED will then extinguish.

An open in the trip circuit wiring between the local fire alarm panel and the Municipal Box (terminals 1 and 2) will cause the amber Remote Station trouble LED to light. A common trouble signal on the local fire alarm system will also sound and the Trouble contacts on this module will transfer.

3.10.3 REVERSE POLARITY MODULE

(w/ 24VDC Auxiliary Power)

The Catalogue 6616-B713 Reverse Polarity Module provides one set of "C" Alarm contacts, one set of "C" Trouble contacts, a Class D Reverse Polarity output and two 24VDC sources. (See 3.11 for 24VDC Auxiliary Power description.) Contacts are rated at 5.0 Amp resistive/2.5 Amp inductive at 28VDC/120VAC.

Under normal supervisory conditions, a current limited between 2.55mA and 9.9mA DC is supplied at output terminals 1 and 2. An alarm on the fire alarm system will cause the output polarity to reverse. The current remains limited between 2.55mA and 9.9mA DC under an alarm condition. (Nema Standard 933-1989).

The transmission of an alarm may be inhibited by the Ancillary Disconnect switch located on the Common Control Bin Assembly cover.

After testing the wiring, make connections to the designated terminals as shown in Figure 10B.

6616-B713 modules may be inserted into either Bin Assembly as indicated in Chart A. Detailed circuit operation is shown on Drawing C46000-0778 supplied with the module and in Appendix B.




FIG. 10B

3.11 AUXILIARY POWER MODULE

The Catalogue #6616-B714 Auxiliary Power Module provides terminals for two D.C. sources. Reconfigurable 24VDC/500mA, filtered and battery backed with no break on transfer, is available from terminals 11 and 12. Non reconfigurable 24VDC/3.0A, unfiltered and battery backed with break on transfer, is available from terminals 13 and 14.

Each Bin Assembly will support a maximum of 4.0 Amps of combined Signal and Unfiltered Auxiliary current.

The 6616-B714 may be installed in either Bin Assembly as indicated in Chart A. Connect field wiring to the terminals as shown in Figure 11.

Detailed circuit operation is shown on Drawing C46000-0888 supplied with the module and in Appendix B.




FIG. 11

3.12 ANNUNCIATOR DRIVER MODULE

The Catalogue 6616-B402 Annunciator Driver Module provides a supervised connection for one remote, 16 zone, LED annunciator. Two 6616-B402 modules may be used when two 16 zone annunciators or one 32 zone annunciator is required. Four 6616-B402 modules may be used when two 32 zone annunciators are required.

Note: 1) When two annunciators are required with common controls, a 6616-B403 Expanded Features module is required.

2) Only capable of one remote annunciator when an I/O programming module is required.

The 6616-B402 module is generally inserted into bin location 6. If this location is required for another module, remove the display driver cable from bin location 7 and reconnect to the matching connector socket on the 6616-B402 module. The zero ohm resistor (beige with black ring) must also be removed from the module. See Note "A" on Drawing C46000-0776 supplied with the module or in Appendix B.

After testing the wiring, connect the circuitry to the designated terminals as shown in Figure 12.

Note: All unused circuits on the annunciator driver module must be jumpered to common to complete Annunciator supervision.




FIG. 12

3.13 **EXPANDED FEATURES MODULE**
 Catalogue 6616-B403 Expanded Features Module provides terminals for a second Remote Trouble Unit or system common controls located in a Remote Annunciator.

The 6616-B403 may be inserted into module location 8 of the common control bin assembly. Connect field wiring as shown in Figure 13.

See Drawing C46000-1055 supplied with the module and in Appendix B for wiring information.




FIG. 13

MODULE LOCATION CHART

MODULE:	COMMON CONTROL BIN ASS'Y								EXPANDED CONTROL BIN ASS'Y							
	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8
660-1350 SERVICE INTERRUPT MODULE		✓	✓	✓	✓	✓				✓	✓	✓	✓	✓		
660-1351 ALARM OUTPUT MODULE		✓	✓	✓	✓	✓				✓	✓	✓	✓	✓		
660-1352 ANNUNCIATOR RELAY MODULE		✓														
660-1353 12V BATTERY MODULE						✓	✓							✓	✓	
660-1354 COMMON CONTROL MODULE								✓								
660-1355 ANNUNCIATOR RELAY MODULE						✓	✓							✓	✓	
660-1356 EXPANDED FEATURES MODULE																
660-1357 BINARY SIGNAL MODULE		✓													✓	✓
660-1358 MINORAL TIE MODULE		✓													✓	✓
660-1359 REVERSE POLARITY MODULE		✓													✓	✓
660-1360 AUXILIARY POWER MODULE		✓	✓	✓	✓	✓				✓	✓	✓	✓	✓		✓
W. FRIEL, E.D. JONES	1 - 43				✓						✓					
W. FRIEL, E.D. JONES	5 - 11				✓						✓					
W. FRIEL, E.D. JONES	12 - 42					✓							✓			
W. FRIEL, E.D. JONES	43 - 16	✓					✓			✓				✓		

- NOTES:
- ① MODULE SUPPLIED WITH BARED B-TERMS.
 - ② MAXIMUM OF 4 RECEIVING MODULES (COMBINATIONS OF ALARM AND SUPERVISORY) PER COMMONS BUS.
 - ③ MAXIMUM OF 2 A.C. OR COMBINED SIGNAL AND AUXILIARY PER COMMONS BUS.
 - ④ ALARM SIGNALS SHOULD BE CORRELATED PER A.P.S. LOCATION CHART ABOVE.
 - ⑤ MODULES OF 4 MATRIX MODULES PER COMMONS.

CHART 14

3.14 FIELD SELECTABLE FEATURES

An eight position dip switch is provided on the front of the 6616-B451 Common Control module to set the following system features.

3.14.1 ONE MINUTE MANUAL ALARM SILENCE AND RESET INHIBIT

The control panel is supplied from the factory with the one minute inhibit feature disabled. To enable the one minute alarm silence feature please switch 1 to the ON position.

3.14.2 ALARM SIGNAL RATE

The control panel is supplied with the signal rate set for continuous output.




FIG. 14

To set the signal rate to 120 ppm, set switch 3 to the ON position. Switch 4 must be in the OFF position.

To set the signal rate to 3-3-3, set switch 4 to the ON position. Switch 3 must be in the OFF position.

FIELD SELECTABLE FEATURES

AN EIGHT POSITION DIP SWITCH IS PROVIDED TO SET THE SYSTEM OPERATION, AS SHOWN IN THE FOLLOWING TABLE.

SWITCH NO.	POSITION	DESCRIPTION OF THE SWITCH ACTION
1	ON	ENABLE THE PUBLIC BELL SIGNAL FEATURE
2	OFF	LEAVE IN "ON" POSITION
3	ON	ENABLE 3-3-3 OUTPUT FOR SIGNALS
4	ON	ENABLE 120 PPM. OUTPUT FOR SIGNALS
5	ON	15 MINUTE AUTO. SIGNAL SILENCE
6	ON	5 MINUTE AUTO. SIGNAL SILENCE
7	ON	4 MINUTE AUTO. SIGNAL SILENCE
8	ON	2 MINUTE AUTO. SIGNAL SILENCE

NOTES:

1. LEAVE SWITCH IN THE "ON" POSITION.
2. FOR CONTINUOUS SIGNALS, SWITCHES 5 AND 7 MUST BE OFF.
3. SWITCHES 5 THROUGH 8 ARE ADDITIVE, I.E. FOR 20 MINUTE AUTO. SIGNAL SILENCE, TURN ON SWITCHES 5 AND 7. WITH SWITCHES 5 THROUGH 8 OFF, NO AUTOMATIC SIGNAL SILENCE WILL OCCUR.

FIG. 14A

3.14.3 AUTOMATIC SIGNAL SILENCE TIMER

The control panel is supplied with the automatic signal silence timer disable.

The required signal silence timer period may be selected by operating any combination of switch 5 to switch 8. The timers are additive, i.e. for 20 minute auto signal silence, turn on switch 5 (15 minutes) and switch 7 (4 minutes).

For details refer to Figure 14A and Drawing C46000-1079 in Appendix B.

3.15 PRIMARY, SECONDARY AND SYSTEM POWER

The primary power circuit must be a separate circuit protected by an over current device in accordance with NFPA 72A and the National Electrical Code. No other equipment can be connected to this circuit. The panel's primary source requirement is 120V, 60 Hz 15 amp. max.

3.15.1 CONNECTIONS FOR THE 6616 CONTROL PANEL

The 6616 Control panel will consist of Common Control Bin Assembly, a Power Supply and Battery.

Connect the Power Supply to the Bin Assembly with the Interconnect cable provided. Connect the Battery to the Power Supply with the leads provided, red (+) and black (-).

Connect 120VAC Primary Power to terminals L, N and G as shown in Figure 15. Connect the ground lead from the Power Supply to the stud in the wallbox. Turn on AC Power.




FIG. 15

3.15.2 CONNECTIONS FOR THE 6632 CONTROL PANEL

The 7532 Control Panel will consist of a Common Control Bin Assembly, Expander Control Bin Assembly, two Power Supplies and two Batteries.

Connect each Power supply to each Bin Assembly with the interconnect cables provided. Use the interconnect cable supplied with the 6632-B902/B904 Expander Control Bin Assembly to connect P11 of the Common Control Bin to the lower left power supply. The interconnect cable supplied with the 6616-B902/B904 Common Control Bin Assembly is used to connect P11 of the Expander Bin to the lower right power supply. Remove the jumper from P10 of the Common Control motherboard and place it in position "A", between module locations 8 and 9 of the same board. Remove the jumper from P10 of the Expander Control motherboard and insert it into position "B", between module locations 8 and 9 of the same board as shown in Figure 15A. Then connect the two Bin assemblies with the ribbon cable provided. When configuring a 6632-B904 with a 6632-B904, a single wire is required to interconnect the terminals on the back of the Common and Expander Control Front Panels. Connect each Battery to each Power Supply with the leads provided, red (-) and black (+). Connect the 120VAC primary power to terminals L, N and G as shown in Figure 15B. Interconnect the two supplies. Connect the ground lead from each Power Supply to the studs in the wallbox. Turn on the AC power.




FIG. 108




FIG. 109

4.0 SYSTEM CHECK-OUT PROCEDURES

4.1 GENERAL INFORMATION

The system check-out procedure consists of basic alarm and trouble tests to check for proper operation of the panel and signalling devices after installation has been completed. These tests should be conducted only by MIRTONE SERVICE PERSONNEL or qualified fire alarm system service personnel. Notify fire headquarters and building occupants before and after tests are conducted.

4.2 PRELIMINARY TEST

With AC and battery power to the system on, verify that only the POWER ON LED is on. If there are any trouble indications correct faults before proceeding.

The POWER ON indicator remains on while the main AC power is supplied.

4.3 INDICATOR TEST

With the system in the normal mode (only POWER ON LED illuminated) operating the Smart Switch, will cause a three second lamp test to be performed. All zone indicators, (light emitting diodes, LED's) illuminate and the common trouble buzzer will pulse.

4.4 INSTALLATION VERIFICATION

(Available on 6516-B904 Common Control Assembly only) Placing the Installation Verification switch in the Verification position will, illuminate the indicating LED, initiate the common trouble sequence and allow the serviceman to verify the continuity of the field wiring. In the verification mode, activation of a resettable initiating device will:

- a) illuminate the corresponding zone alarm LED.
- b) sound a distinct code (two pulses) on the alarm signals to inform the Service personnel that the device is properly installed.

The control panel will automatically reset after the initiating device has been restored to allow the testing of another device.

Returning the Installation Verification switch to the normal position will return the system to the normal supervisory mode. These tests should only be conducted by an Authorized Fire Alarm System Representative.

4.5 ALARM TEST

Initiate an Alarm-Operate a restorable device on Zone 1 and verify that:

- a) all signals sound and operate at the set rate (continuous or 120 ppm or 3/3/3 code).
- b) the applicable zone alarm LED and common alarm LED illuminate steady.
- c) the Silence Alarm Operator Prompt LED will illuminate to indicate the Smart Switch may be used to silence the signals. Press and release the Smart Switch. Verify that:
 - 1) The signal's silence and the alarm silenced LED illuminates.
 - 2) The Initiating zone LED remains ON.
 - 3) The Common Trouble LED and trouble horn flash.

If the system is configured with 1 minute reset inhibit the signals cannot be silenced for 1 minute after initiation of the first alarm.

For systems with Ancillary Alarm Relays - verify that the relay contacts transfer for the control of ancillary functions.

For systems with a Remote Station Module connected - verify that the headquarters or the remote station have received the alarm.

When the alarm signals have been silenced, the Silence Trouble, Operator Prompt LED will flash to indicate the Smart Switch may be used to silence the trouble horn. Press and release the Smart Switch. The trouble horn will silence but the Zone LED, Common Alarm LED and Alarm Silenced LED will remain ON and the Common Trouble LED will continue to flash.

The Reset, Operator Prompt LED will illuminate to indicate the panel may be RESET by the Smart Switch after the initiating device has been restored. The system will perform a three second lamp test cycle of all indicators during the RESET cycle. The ALARM TEST procedure should be repeated for all receiving circuits.

4.6 DISCONNECT TEST

The Ancillary Disconnect Switch will disconnect the 6616-B321 Ancillary Relay module contacts, the 6616-B831 I/O programming module contacts and the 6616-B700 Series Fire Dept. module if provided.

Place the Ancillary Disconnect switch in the disconnect position and verify that:

- the trouble buzzer pulses and the common TROUBLE LED flashes at the control panel and remote trouble unit (if installed). The OPERATOR PROMPT LED will flash to indicate the trouble buzzer may be silenced.
- operation of the Smart Switch will silence the trouble buzzer and illuminate the OPERATOR PROMPT LED to indicate the system may be reset.
- a system trouble has been received by the Fire Department or Remote Station if a trouble signal transmission is required.

Initiate an alarm and verify that:

- the Fire Department or remote station did not receive the alarm if a 6616-B700 series module is provided.

- the Ancillary Relay module contacts did not transfer if a 6616-B321 or 6616-B301 is provided.

Return the Disconnect switch to the normal position. Reset initiating device and operate the system Smart Switch. Verify that:

- the system resets
- the trouble transmission to the Fire Department or Remote Station has cleared.

4.7 OPEN CIRCUIT TEST

Remove one wire of an alarm receiving circuit from the control panel. Verify that:

- the Common Trouble buzzer and TROUBLE LED flash.
- the ZONE FAULT LED illuminates.
- the individual ZONE TROUBLE LED (located on the zone module) illuminates.

The OPERATOR PROMPT LED will flash to indicate the SMART SWITCH may be used to silence the trouble buzzer. Press and release the SMART SWITCH. The trouble buzzer will silence but the ZONE TROUBLE LED will remain on and the common TROUBLE LED will continue to flash. The OPERATOR PROMPT LED will transfer to the reset position.

Reconnect the alarm receiving circuit wire to the control panel. Verify the ZONE FAULT LED, individual ZONE TROUBLE LED and OPERATOR PROMPT LED turn off and the common trouble circuit restores.

This should be repeated for all receiving and signal circuits.

4.8 BATTERY POWER TEST

Place the system on battery power by turning off the AC primary power. Verify that:

- the POWER ON LED turns off
- the trouble sequence activates.

Reconnect the primary power.

4.9 BATTERY SUPERVISION TEST

Caution: The battery contains sufficient stored energy to cause personnel injury if shorted. Remove all metal objects from hands and arms such as rings, watches, bracelets and other metallic objects.

Disconnect one of the battery loads. Verify that:

- the BATTERY FAULT LED turns on
- the trouble sequence activates.

Reconnect the battery.

5.0 OPERATIONS

5.1 FUNCTIONS OF CONTROL SWITCHES AND INDICATORS

All operator controls and function indicators are conveniently located on the Common Control Dln/Assembly front panel. Operations are simplified by the multifunction Smart Switch with Operator prompt LED's for RESET, SILENCE ALARM, and SILENCE TROUBLE functions.

In the alarm mode the Silence Alarm prompt LED will illuminate indicating that the operation of the Smart Switch will silence the trouble signal.

In the trouble mode the Trouble Silence prompt LED will flash indicating that the operation of the Smart Switch will silence the trouble signal.

Illumination of the Reset prompt LED will indicate that the operation of the Smart Switch will reset the system. Resetting the control panel when there is an alarm present will immediately reinitiate the alarm sequence. Similarly, attempting to Reset the control panel while a fault condition exists will initiate the common trouble sequence.

In addition to the Smart Switch the panel provides the following switches, SILENT TEST, DRILL, ANCILLARY DISCONNECT and the following common indicators, POWER ON, ALARM, ALARM SILENCED, ZONE FAULT, GROUND FAULT, BATTERY FAULT, SILENT TEST ON, and INDIVIDUAL ZONE ALARM LED'S.

The 6616/6632-2904 assembly provides INSTALLATION VERIFICATION, ALARM VERIFICATION, and INDIVIDUAL ZONE BYPASS in addition to the above features.

5.2 SILENT TEST SWITCH

Placing the Silent Test Switch in the Silent Test position will illuminate the silent test LED, initiate the common trouble sequence and inhibit operation of the alarm output circuits. Operating an initiating device will cause the respective zone LED to illuminate, the ancillary relay and the Fire Dept. module to operate. Subsequent operation of the Silent Test Switch and the Smart Switch will return the Control panel to the normal supervisory mode. The control panel will automatically return to the normal supervisory mode if no alarm is initiated within a thirty minute time period.

5.3 DRILL SWITCH

Operating the Drill switch will cause the signals to sound at the selected rate. The ancillary alarm relay will remain de-energized and the signal

silence function will be operative for the duration of the drill. Returning the Drill switch to the normal position will silence the signals and return the system to the normal supervisory mode. If during an alarm, the signals have been silenced, they may be reactivated by operating the Drill switch.

5.4 ANCILLARY DISCONNECT SWITCH

Operating the Ancillary Disconnect switch will illuminate the Ancillary Disconnect LED, initiate the common trouble sequence, inhibit the operation of the 6616-2321 and 6616-2331 ancillary relays and Fire Dept. modules. Returning the Ancillary Disconnect switch to the normal position will return the system to the normal supervisory mode.

5.5 ALARM VERIFICATION

(Available on the 6616/6632-2904 assemblies only)

Selecting a zone for Alarm Verification will delay the processing of a change in status from the zone selected for 20 seconds. If the alarm is still present at the end of the 20 second delay (reset period), or if the alarm re-occurs within the following 80 seconds, then the alarm will be processed immediately.

If the change in status is the result of an electrical transient or migratory products of combustion, the panel will return to the normal supervisory mode. Only smoke detectors should be connected to a zone selected for Alarm Verification.

5.6 INDIVIDUAL ZONE BYPASS

(Available on the 6616/6632-2904 assemblies only)

Placing a Zone Bypass switch in the bypass position will disable the transmission of an alarm pulse from the corresponding receiving zone, initiate the common trouble sequence and illuminate the zone trouble LED. If an initiating device is activated on a bypassed zone, the signal circuits and relays will not be activated. The Reset Operator Prompt LED will illuminate to indicate the panel may be RESET by the Smart Switch after the initiating device has been restored. Returning the switch to the Normal position will return the system to the normal supervisory mode.

5.7 AC POWER ON LED

The GREEN LED indicates when AC Power is supplied to the control panel. Degradation of AC power will cause the Power On LED to extinguish and the panel to transfer to standby battery power.

5.8 ALARM ZONE LED

The RED common alarm LED will illuminate upon the receipt of an alarm and remains illuminated until system RESET.

5.9 ALARM SILENCED LED

The AMBER ALARM SILENCED LED will illuminate following the silence alarm function of the smart switch and will remain illuminated until system RESET or the receipt of a subsequent alarm.

5.10 ZONE FAULT LED

The AMBER ZONE FAULT LED will illuminate following the receipt of a zone fault in the supervised field wiring of the alarm receiving or alarm output circuits.

5.11 GROUND FAULT LED

The AMBER GROUND FAULT LED will illuminate when a ground fault of 10 to 50K Ohms is detected and remains illuminated while the fault is present.

5.12 BATTERY FAULT LED

The AMBER BATTERY FAULT LED will illuminate if the battery is low or disconnected during normal operations.

5.13 SILENT TEST ON

The AMBER SILENT TEST ON LED will illuminate when the silent test switch is operated and will remain illuminated for the duration of the silent test.

5.14 ANCILLARY DISCONNECT LED

The AMBER ANCILLARY DISCONNECT CONFIRMATION LED will illuminate to confirm the operation of the ancillary disconnect switch. It will remain illuminated until the ancillary disconnect switch is returned to the normal position.

5.15 COMMON TROUBLE LED

The AMBER COMMON TROUBLE LED will flash during the common trouble sequence. It will remain flashing until the fault is corrected and the system is reset.

6.0 OPERATION MODES

6.1 GENERAL INFORMATION

The Fire Alarm Control Panel has three modes of operation, the supervisory mode, the alarm mode, and the trouble mode.

6.2 SUPERVISORY

The fire alarm system is in the supervisory mode when the GREEN, AC Power On LED is illuminated and all other LED's are extinguished.

6.3 ALARM

Activation of an automatic detector or manual pull station will cause the signals to sound at the selected rate, the alarm zone LED, the common alarm LED and the silence alarm operator prompt LED to illuminate. The optional Fire Department and Ancillary Alarm Contacts, if provided, will activate.

After investigation of the alarm, the signals may be silenced by confirming the silence alarm prompt LED is illuminated and operating the Smart Switch. Operating the switch in this mode will silence the alarm signals, illuminate the alarm silenced LED and activate the common trouble sequence. The signals cannot be silenced for one minute if the one minute inhibit feature has been selected. The signals will automatically silence after a selected period if the 2 to 30 minute auto silence feature has been selected. Operation of the Smart Switch to silence the alarm signals will not effect the state of the ancillary contacts.

If the alarm has been silenced, a subsequent alarm from another alarm receiving zone will cause the signals to resound. The signals may be silenced immediately by operating the Smart Switch or by the automatic signal silence feature, if selected. The ancillary alarm contact and the Remote Station Module will remain energized. The alarm will continue until the initiating device is returned to its normal condition and the system is reset. The control panel may be reset by confirming the reset prompt LED is illuminated and operating the Smart Switch. Operation of the Smart Switch after the initiating device has been restored, will return the system to the normal supervisory mode.

Activation of a supervisory device connected to a supervisory receiving module will cause the individual zone alarm LED and the zone fault LED to illuminate, the common trouble sequence to be initiated and the trouble silence prompt LED to illuminate.

After investigation of the supervisory alert the trouble signal may be silenced by operating the Smart Switch. Operating the switch in this mode will silence the trouble signal and illuminate the reset prompt LED. Restoring the supervisory device and activating the Smart Switch will return the system to the normal supervisory mode.

6.4 RESPONDING TO AN ALARM

WHEN AN ALARM SOUNDS:

1. Notify the municipal fire departments.
2. Evacuate all occupants from the building in an orderly manner. Avoid panic.
3. To reset the system after an alarm:
 - a) Reset or replace as applicable the alarm initiating device(s).
 - b) Open the panel door and operate the Smart Switch.

6.5 TROUBLE

A fault on any supervised circuit, the off normal condition of a control switch, the removal of any interconnect cable or module from its position or loss of stand-by battery power will cause the common trouble LED to flash, the ancillary trouble relay to de-energize the remote trouble unit to operate (if provided) and the zone trouble LED to illuminate (if the fault is on the field wiring). The trouble mode will be suppressed during alarm.

After investigation of the fault, the trouble signal may be silenced by confirming the silence trouble prompt LED is illuminated and operating the Smart Switch. Operating the switch in this mode will silence the trouble signal, and illuminate the reset prompt LED. Operation of the Smart Switch to silence the trouble signal will not affect the state of the ancillary trouble relay.

A subsequent trouble on any other supervised circuit will cause the associated trouble LED to turn on.

The control panel will return to the supervisory mode after the fault or off normal condition has been restored.

The degradation of AC power will cause the control panel to transfer to standby battery power, initiate the common trouble sequence and extinguish the green Power ON LED.

6.6 RESPONDING TO A TROUBLE

WHEN THE TROUBLE SIGNAL SOUNDS:

1. Open the panel door and operate the SMART SWITCH. This:
 - (a) Silences the trouble tone.
 - (b) Leaves the system COMMON TROUBLE LED flashing.
2. Notify the responsible system maintenance personnel that there is a system trouble.

3. If any manual station will be out of service for an extended period of time, place an "OUT OF ORDER" sign on the affected station and indicate the location of the nearest operating station.

7.0 PERIODIC SYSTEM OPERATIONAL TEST OR DRILL

7.1 GENERAL INFORMATION

A system operational test and/or drill must be made according to and at the intervals required by local fire authorities. Where there are no conflicting local regulations, a monthly test or drill is recommended. Should a trouble condition occur during a test or drill, the system must be serviced by a qualified fire alarm service technician.

When the panel includes an optional Remote Station module and a test or drill is to be performed, notify the fire department or remote station of scheduled test and disconnect the circuit by placing the Ancillary Disconnect Switch in the DISCONNECT position. This causes the audible tone to pulse and the TROUBLE LED to flash. The audible tone can be silenced by operating the SMART SWITCH with the SILENCE TROUBLE LED illuminated.

7.2 INITIATING A TEST OR DRILL

A test or drill can be initiated from any manual station.

1. Open the station and place the switch in the ALARM TEST (up) position and check that:
 - (a) Audible signals sound at the selected rate.
 - (b) Respective Zone Alarm LED illuminates.
 - (c) The Fire Department or Remote Station did not receive the alarm.

A different station should be used for each test or drill to ensure that each station will be checked periodically. A record should be maintained of all tests and drills and the station from which they were originated.

CAUTION

Never attempt to initiate a test or drill by holding a flame beneath an automatic heat detector. This will destroy its fixed temperature element and require replacement of the entire unit.

2. When the test of r/s1 has been completed:
 - (a) Return the manual station switch to the NORMAL (down) position and close the station.
 - (b) Place the Ancillary Disconnect switch in the NORMAL position.
 - (c) Operate the SMART SWITCH with the RESET PROMPT LED illuminated. Verify that the applicable zone alarm LED has extinguished and the Trouble transmission to the Fire Department or Remote Station has cleared.

Edwards products are designed and specified to provide optimal battery performance when installed in ambient room temperatures of 20° - 25°C (68° - 77°F). While testing agencies such as ULC and UL perform operational tests over the range of 0° - 42°C (32° - 120°F), continued operation above the optimal range will result in reduced battery life expectancy.

APPENDIX A BATTERY SELECTION

THE AMPERE-HOUR RATING OF EACH BATTERY REQUIRED WILL DEPEND ON ITS BIN/ASSEMBLY LOAD.

1. When Auxiliary DC is not required from a bin/power supply assembly:
 - The 6.5 Ah battery will support a loaded bin for 24 hour supervision and 5 minutes alarm.
 - The 10.0 AH battery will support a loaded bin for 24 hour supervision and 30 minutes alarm.
2. When Auxiliary DC is required from a bin/power supply assembly, calculate the minimum size of battery needed to support the bin incorporating the auxiliary power as follows:

A. CALCULATE TOTAL BIN/POWER SUPPLY LOAD:

MODULES	QTY	SUP/ALM (mA)	=	SUP/ALM (mA)
Number of 6616-351 modules	___ x	45 / 156	=	___ / ___
Number of 6616-352 modules	___ x	20 / 70	=	___ / ___
Number of 6616-353 modules	___ x	40 / 155	=	___ / ___
Number of 6616-354 modules	___ x	45 / 160	=	___ / ___
Number of 6616-311 modules	___ x	15 / 72	=	___ / ___
Number of 6616-321 modules	___ x	7 / 43	=	___ / ___
Number of 6616-331 modules	___ x	7 / 60	=	___ / ___
Number of 6616-402 modules	___ x	9.5 / 85	=	___ / ___
Number of 6616-403 modules	___ x	22 / 22	=	___ / ___
Number of 6616-701 modules	___ x	7.5 / 25	=	___ / ___
Number of 6616-711 modules	___ x	10 / 279	=	___ / ___
Number of 6616-712 modules	___ x	18 / 358	=	___ / ___
Number of 6616-713 modules	___ x	20 / 33	=	___ / ___
Number of 6616-714 modules	___ x	6.5 / 6.5	=	___ / ___
Bin/Power supply adder			=	65 / 165

	Supervisory	Alarm
Sub-Total current in mA	___ mA	___ mA
Divide Sub-Total by 1000 to convert to Amps		
Total Bin/Power Supply Current:	<input style="width: 50px;" type="text"/> AMPS	<input style="width: 50px;" type="text"/> AMPS

B. CALCULATE TOTAL LOAD ON BATTERY (IN AMPS):

	SUP. (amps)	ALARM (amps)
a. Total alarm output current (Signal Load)	0 ___ *	___ *
b. Auxiliary DC Unloaded	___	___ *
c. Resizable Auxiliary DC	___	___
d. Total Bin/Power Supply current (From A)	___	___
Total Supervisory and Alarm Load	<input style="width: 50px;" type="text"/> AMPS	<input style="width: 50px;" type="text"/> AMPS


* (a+b) must not exceed 4.0 Amps.

C. DETERMINE AMPERE HOUR OF BATTERY FROM APPROPRIATE CURVE


NOTE: Due to charger restrictions, battery cannot exceed 15Ah

EDWARDS 6816/6632 CONTROL PANEL


24 HOURS SUPERVISION & 5 MINUTES ALARM



24 HOURS SUPERVISION & 30 MINUTES ALARM



60 HOURS SUPERVISION & 5 MINUTES ALARM




May 1981, 1980

APPENDIX B

CUSTOMER DRAWINGS

Cat. No.	Description	Dwg. No.	Page
0316-B351	Class B Alarm Receiving Module	45000-1075	B1
6616-B352	Supervisory Receiving Module	45000-1073	B2
6616-B353	Alarm/Supervisory Receiving Module	45000-1071	B3
0016-B354	Class A Alarm Receiving Module	45000-1077	B4
6616-B371	Alarm Output Module	45000-0773	B5
6616-B321	Auxiliary Relay Module	45000-0774	B6
0316-B331	I/O Programming Module	45000-0813	B7
0316-B451	Common Control Module	45000-1079	B8
6616-B402	Annunciator Driver Module	45000-0776	B9
6616-B403	Expanded Features Module	45000-1085	B10
6616-B711	Remote Station Module	45000-0777	B11
6616-B712	Municipal Tie Module	45000-0832	B12
6616-B713	Reverse Polarity Module	45000-0778	B13
0016-B714	Auxiliary Power Module	45000-0833	B14
6616-B801	16 LED Annunciator w/ features	45000-0834	B15
6616-B902	16 LED Annunciator less features	45000-0834	B15
0316-B901	7516 Wallbox / Door Assembly	45000-0779	B16
6616-B902	Common Control Assembly	45000-0827	B17
6616-B904	Common Control Assembly	45000-1081	B18
6616	Control Panel Assembly	45000-0781	B19
6602-B901	7502 Wallbox / Door Assembly	45000-0750	B20
6032-B902	Expander Control Assembly	45000-0839	B21
6632-B904	Expander Control Assembly	45000-1083	B22
6832	Control Panel Assembly	45000-0782	B23
	Device Compatibility Chart	45000-0858	B24
	Operating Instructions	45000-0044	B25

45000-1075
REV. 5-82



FIELD ADDRESS	R.O. DEV. ADDRESS	R.O. DEV. CIRCUIT	R.O. DEV. CIRCUIT
0-15	16-31	16-31	16-31
32-47	32-47	32-47	32-47
48-63	48-63	48-63	48-63
64-79	64-79	64-79	64-79
80-95	80-95	80-95	80-95
96-111	96-111	96-111	96-111
112-127	112-127	112-127	112-127
128-143	128-143	128-143	128-143
144-159	144-159	144-159	144-159
160-175	160-175	160-175	160-175
176-191	176-191	176-191	176-191
192-207	192-207	192-207	192-207
208-223	208-223	208-223	208-223
224-239	224-239	224-239	224-239
240-255	240-255	240-255	240-255





FIG. 4 R.O. DEV. REC - (64-79) 64-79. SEE SUBSTITUTION TABLE IN PP 45200-0075


FIG. 5 R.O. DEV. REC - (80-95) 80-95. REFER TO INDIVIDUAL DEVICE IF APPLICABLE FOR APPLICATION DATA AND TERMINAL DESIGNATIONS

FIG. 6 R.O. DEV. REC - (96-111) 96-111. SEE SUBSTITUTION TABLE IN PP 45200-0075

WIRE GAUGE TO FIELD ADDRESSING	MAXIMUM WIRE FOR
14	40,000FT
16	8,000FT
18	4,000FT
20	2,500FT

COUNTING

COUNTING IS ACCOMPLISHED BY PRESSING MODULES INTO THE CORNER CONTROL AND EXERCISING CONTROL PIN NUMBER AS SHOWN BELOW. EACH PIN ASSEMBLY AT BOTTOM OF EACH MODULE IS A SEPARATE MODULE. THE ZERO COUNT IS INDICATED BY A ZERO IN THE DISPLAY. THE ZERO COUNT IS INDICATED BY A ZERO IN THE DISPLAY. THE ZERO COUNT IS INDICATED BY A ZERO IN THE DISPLAY.



SEE ALSO COMMON CONTROL R.O. DEVICE IN RECEIVER MANUAL FOR DETAIL INFORMATION

DESCRIPTION

THE POINT CONTACT TERMINALS FOR A CLASS B SUPERHETERODYNE DETECTOR AND 4-ARMER ZENER DIODE ARE PROVIDED FOR EACH R.O. DEVICE. EACH CIRCUIT MAY BE SELECTED TO OPERATE AS EITHER A FIELD ADDRESSING DEVICE OR A TRANSMITTER. THE MAXIMUM ADDRESSING IS LIMITED TO FIVE IF OPEN AND SHORT PROTECTION IS PROVIDED AND THE R.O. DEVICE OPERATION. FOR MAXIMUM ADDRESSING CHECK WITH EACH MODULE IS COMPLETED FOR THE PROPER OPERATION BEFORE CANNOTING FIELD ADDRESS.

COMPATIBILITY INFORMATION REFER TO DEVICE COMPATIBILITY CHART 45200-0080. PROVIDED IN THE APPENDIX OF THE MANUAL, FOR A COMPLETE LIST OF EDWARDS COMPATIBLE PRODUCTS.

FOR DETAIL OF SYSTEM INFORMATION, CONSULT MANUAL FEATURES AND MODULE FEATURE INFORMATION FROM THE MANUAL, FOR A COMPLETE LIST OF EDWARDS COMPATIBLE PRODUCTS.

INSTALLATION

THE POINT CONTACT TERMINALS SHOULD BE INSTALLED IN ACCORDANCE WITH THE LATER PARTS OF THE MANUAL. FIELD ADDRESSING. IF LOCAL REGULATIONS PERMIT, COMPLETELY CORRECTED TO THE LOCAL REGULATIONS. COMPLETELY CORRECTED TO THE LOCAL REGULATIONS. COMPLETELY CORRECTED TO THE LOCAL REGULATIONS.

EDWARDS		EDWARDS	
1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32
33	34	35	36
37	38	39	40
41	42	43	44
45	46	47	48
49	50	51	52
53	54	55	56
57	58	59	60
61	62	63	64
65	66	67	68
69	70	71	72
73	74	75	76
77	78	79	80
81	82	83	84
85	86	87	88
89	90	91	92
93	94	95	96
97	98	99	100

FIELD ADDRESS	RECEIVING ADDRESS
0-15	16-31
32-47	48-63
64-79	80-95
96-111	112-127
128-143	144-159
160-175	176-191
192-207	208-223
224-239	240-255
256-271	272-287
288-303	304-319
320-335	336-351
352-367	368-383
384-399	400-415
416-431	432-447
448-463	464-479
480-495	496-511
512-527	528-543
544-559	560-575
576-591	592-607
608-623	624-639
640-655	656-671
672-687	688-703
704-719	720-735
736-751	752-767
768-783	784-799
800-815	816-831
832-847	848-863
864-879	880-895
896-911	912-927
928-943	944-959
960-975	976-991
992-1007	1008-1023

NAME	ADDRESS	PHONE	FAX	TELETYPE	TELEFAX
EDWARDS	1000 N. 10TH ST.	916-435-1000	916-435-1001	916-435-1002	916-435-1003
CUSTOMER TRAINING	1000 N. 10TH ST.	916-435-1000	916-435-1001	916-435-1002	916-435-1003
SUPPLY RECEIVING MODULE	1000 N. 10TH ST.	916-435-1000	916-435-1001	916-435-1002	916-435-1003

INSTALLATION




FIG. 1 CLASS B ALARM OUTPUT




FIG. 2 CLASS B ALARM OUTPUT WITH BELL




FIG. 3 CLASS B ALARM OUTPUT WITH BELL AND BUZZER




FIG. 4 CLASS B ALARM OUTPUT WITH BELL AND BUZZER

INSTALLATION

THE CAT. # 68100-0773 ALARM OUTPUT MODULE PLUGS INTO THE SYSTEM CONTROL AND EXHAUST CONTROL. THE ASSEMBLY AS SHOWN ON FIG. 1 AND FIG. 2 SHOULD BE INSTALLED IN A LOCATION WHERE IT WILL BE PROTECTED FROM VIBRATION AND OTHER EXCESSIVE NOISE. THE BELL AND BUZZER SHOULD BE INSTALLED IN A LOCATION WHERE IT WILL BE PROTECTED FROM VIBRATION AND OTHER EXCESSIVE NOISE. THE BELL AND BUZZER SHOULD BE INSTALLED IN A LOCATION WHERE IT WILL BE PROTECTED FROM VIBRATION AND OTHER EXCESSIVE NOISE.




FIG. 5 CLASS B ALARM OUTPUT

DESCRIPTION

CLASS B ALARM OUTPUT MODULE PROVIDES THREE (3) CLASS B ALARM OUTPUTS. EACH OUTPUT IS AVAILABLE FOR EITHER A BELL OR BUZZER. THE BELL AND BUZZER ARE AVAILABLE FOR EITHER A BELL OR BUZZER. THE BELL AND BUZZER ARE AVAILABLE FOR EITHER A BELL OR BUZZER. THE BELL AND BUZZER ARE AVAILABLE FOR EITHER A BELL OR BUZZER.

FOR MORE INFORMATION, REFER TO THE COMPATIBILITY LIST ON THE BACK OF THE MANUAL FOR A COMPLETE LIST OF DEVICES COMPATIBLE WITH THIS SYSTEM. THE COMPATIBILITY LIST IS LOCATED ON THE BACK OF THE MANUAL FOR A COMPLETE LIST OF DEVICES COMPATIBLE WITH THIS SYSTEM.

THE SYSTEM CONTROL AND EXHAUST CONTROL MODULES ARE LOCATED ON THE SYSTEM CONTROL AND EXHAUST CONTROL MODULES. THE SYSTEM CONTROL AND EXHAUST CONTROL MODULES ARE LOCATED ON THE SYSTEM CONTROL AND EXHAUST CONTROL MODULES.

INSTALLATION


THE CLASS B ALARM OUTPUT MODULE SHOULD BE INSTALLED IN ACCORDANCE WITH THE LATEST EDITION OF THE NATIONAL ELECTRICAL CODE, ARTICLE 760. THE CLASS B ALARM OUTPUT MODULE SHOULD BE INSTALLED IN ACCORDANCE WITH THE LATEST EDITION OF THE NATIONAL ELECTRICAL CODE, ARTICLE 760.

THE CLASS B ALARM OUTPUT MODULE SHOULD BE INSTALLED IN ACCORDANCE WITH THE LATEST EDITION OF THE NATIONAL ELECTRICAL CODE, ARTICLE 760. THE CLASS B ALARM OUTPUT MODULE SHOULD BE INSTALLED IN ACCORDANCE WITH THE LATEST EDITION OF THE NATIONAL ELECTRICAL CODE, ARTICLE 760.

POSITION	WARRANTY	REPAIR	REPLACE	REPAIR	REPLACE
CLASS B ALARM OUTPUT	1	1	1	1	1
CLASS B ALARM OUTPUT	1	1	1	1	1
CLASS B ALARM OUTPUT	1	1	1	1	1


POSITION	WARRANTY	REPAIR	REPLACE	REPAIR	REPLACE
CLASS B ALARM OUTPUT	1	1	1	1	1
CLASS B ALARM OUTPUT	1	1	1	1	1
CLASS B ALARM OUTPUT	1	1	1	1	1

WARNING
 This drawing is intended for use only as a guide. The user is responsible for the proper installation and use of the equipment. The manufacturer is not responsible for any damage or injury caused by the use of the equipment.




NOTES:
 1. THIS DRAWING IS INTENDED FOR USE ONLY AS A GUIDE.
 2. THE USER IS RESPONSIBLE FOR THE PROPER INSTALLATION AND USE OF THE EQUIPMENT.
 3. THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY DAMAGE OR INJURY CAUSED BY THE USE OF THE EQUIPMENT.

DESCRIPTION
 This drawing shows the details of the fire alarm system component. It includes the mounting bracket, the control panel, and the detector unit. The drawing is intended for use as a guide for installation and use.







NOTES:
 1. THIS DRAWING IS INTENDED FOR USE ONLY AS A GUIDE.
 2. THE USER IS RESPONSIBLE FOR THE PROPER INSTALLATION AND USE OF THE EQUIPMENT.
 3. THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY DAMAGE OR INJURY CAUSED BY THE USE OF THE EQUIPMENT.

WARNING
 This drawing is intended for use only as a guide. The user is responsible for the proper installation and use of the equipment. The manufacturer is not responsible for any damage or injury caused by the use of the equipment.




NOTES:
 1. THIS DRAWING IS INTENDED FOR USE ONLY AS A GUIDE.
 2. THE USER IS RESPONSIBLE FOR THE PROPER INSTALLATION AND USE OF THE EQUIPMENT.
 3. THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY DAMAGE OR INJURY CAUSED BY THE USE OF THE EQUIPMENT.



MOUNTING

THE CAT 3 6845-0438 COMMON CONTROL MODULE IS FACTORY INSTALLED IN THE 6845-0438 COMMON CONTROL BOX ASSEMBLY.



DESCRIPTION

EACH MODULE PROVIDES SIGNALS FOR 4 WIRE (ABLE UNIT OR SYSTEM COMMON CONTROL IS LOCATED IN 4 WIRE UNIT ONLY).

4 WIRE POSITION PULSE IS PROVIDED TO THE SYSTEM UNIT. THE SIGNALS ARE SHOWN IN THE FOLLOWING TABLE.

ENVELOPE	THE PIN POSITION OF THE SWITCH IN
1	ENABLE ONE WIRE SIGNAL SILENCE (MUTE)
2	ENABLE OR DELOTTION
3	ENABLE 2 WIRE OUTPUT FOR SIGNALS
4	ENABLE 3 WIRE OUTPUT FOR SIGNALS
5	ENABLE 4 WIRE OUTPUT FOR SIGNALS
6	RETRACT AUTOMATIC SIGNAL SILENCE
7	RETRACT AUTOMATIC SIGNAL SILENCE
8	RETRACT AUTOMATIC SIGNAL SILENCE


NOTE - (1) LOGIC SWITCH 2 IN THE "UP" POSITION
 (2) FOR SIGNALS SIGNALS 3 AND 4 MUST BE "UP"
 (3) SWITCHES 5 THRU 8 USE ADDITIONAL WIRE EXAMPLE FOR 20 WIRE UNIT SIGNAL SILENCE TURN ON SWITCHES 6 AND 7, SWITCHES 3 THRU 5 WILL BE AUTOMATIC SIGNAL SILENCE WILL OCCUR.

FOR DETAILED SYSTEM OPERATION, COMMON CONTROL FEATURES AND WIRE PLUMBING, REFER TO THE INSTALLATION AND OPERATION MANUAL PP 45300-1700.



INSTALLATION

FOR A NEW SYSTEM DESIGN, THIS SHOULD BE INSTALLED IN ACCORDANCE WITH THE FOLLOWING ISSUES OF THE NATIONAL FIRE ALARM CODE, ARTICLE 760.

EDWARDS	
CUSTOMER DRAWING	
CAT. 6845-0431	
COMMON CONTROL MODULE	
DATE	BY
REV	DATE
NO	BY
45300-1700	




SECTION LINE
REMOVE THIS SECTION FOR SERVICE



WIRE GAUGE	MAXIMUM WIRE RUN
14	10.000 FT
16	5.000 FT
18	4.000 FT
20	2.500 FT


Common (-) (2) for Leads

FORM 60000-07/78
REVISED PER 60000-07/78



INSTALLATION

THE NATIONAL CAT # 555-380-000 ANNUNCIATOR DRIVER MODULE SHOULD BE INSTALLED IN THE COMMON ELECTRICAL CABINET. THE COMMON ELECTRICAL CABINET SHOULD BE INSTALLED IN THE COMMON ELECTRICAL CABINET. THE ANNUNCIATOR DRIVER MODULE SHOULD BE INSTALLED IN THE COMMON ELECTRICAL CABINET. THE ANNUNCIATOR DRIVER MODULE SHOULD BE INSTALLED IN THE COMMON ELECTRICAL CABINET.




IF LOCATION IS USED FOR ANNUNCIATOR DRIVER MODULE, THE ANNUNCIATOR DRIVER MODULE SHOULD BE INSTALLED IN THE COMMON ELECTRICAL CABINET. THE ANNUNCIATOR DRIVER MODULE SHOULD BE INSTALLED IN THE COMMON ELECTRICAL CABINET.

DESCRIPTION

THE ANNUNCIATOR DRIVER MODULE IS USED TO DRIVE THE ANNUNCIATOR DRIVER MODULE. THE ANNUNCIATOR DRIVER MODULE IS USED TO DRIVE THE ANNUNCIATOR DRIVER MODULE. THE ANNUNCIATOR DRIVER MODULE IS USED TO DRIVE THE ANNUNCIATOR DRIVER MODULE.


INSTALLATION

THE ANNUNCIATOR DRIVER MODULE SHOULD BE INSTALLED IN ACCORDANCE WITH THE LATEST ISSUES OF THE NATIONAL ELECTRICAL CODE (NEC) ARTICLE 708.



ANNUNCIATOR CIRCUIT NOMINAL AND MINIMUM




WIRE GAUGE	MAXIMUM WIRE LENGTH FOR COMMON
14	4000 FT
15	2500 FT
17	1500 FT
18	1000 FT



1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24
25	26	27	28	29	30
31	32	33	34	35	36
37	38	39	40	41	42
43	44	45	46	47	48
49	50	51	52	53	54
55	56	57	58	59	60
61	62	63	64	65	66
67	68	69	70	71	72
73	74	75	76	77	78
79	80	81	82	83	84
85	86	87	88	89	90
91	92	93	94	95	96
97	98	99	100	101	102

EDWARDS
CUSTOMER DRIVING
CAT. 555-380-000
ANNUNCIATOR DRIVER MODULE

48000-0777
REV. 10-80




NOTE: WIRE THE SYSTEM WITH THE WIRE STATIONS REFERRED TO IN THIS MANUAL.

NOTE: WIRE THE SYSTEM WITH THE WIRE STATIONS REFERRED TO IN THIS MANUAL.

MOUNTING

THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE ASSEMBLY IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE ASSEMBLY IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT.



THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE ASSEMBLY IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT.

DESCRIPTION

THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE ASSEMBLY IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT.

THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE ASSEMBLY IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT.

THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE ASSEMBLY IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT.

INSTALLATION


THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE ASSEMBLY IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT. THE UNIT IS MOUNTED ON THE WALL WITH THE CONTROL PANEL ON THE LEFT.

1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10

MOUNTING		MOUNTING	
1	2	3	4
1	2	3	4







FORM 4 (REVISED 10-72)



TERMINAL BLOCK

RECEIVER




IF MUNICIPAL BOX HAS TWO (2) CONTACTS WHICH OPERATE AT THE JUNCTION OF THE TRIP, THESE SHOULD BE WELDED INTO A TRIP ALARM DETECTING CIRCUIT TO BE CONNECTED TO A MANUAL STATION ALARM. IT IS RECOMMENDED THAT OPERATION OF THE MANUAL BOX SHOULD CAUSE THE LOCAL FIRE ALARM SIGNALS TO SOUND.

NO. OF WIRING POINTS	11
NO. OF WIRING POINTS	11
NO. OF WIRING POINTS	11

MOUNTING

THE CAT 4 TRIP UNIT MOUNTING THE MODULE MUST BE MOUNTED INTO THE COMMON CONTROL OR CONTROL BIN ASSEMBLY TO BE MOUNTED ON THE BIN WITH THE PULLER OR CAPACITY WITH BLACK PENDING LABELS. THE CONNECTOR PINS ON THE BIN SHOULD BE REMOVED FROM THE MODULE TO BE MOUNTED. REMOVE EACH PULLER FROM BIN ASSEMBLY WITH THE UNIT. PLEASE REMOVED BEFORE PULLER IS MOUNTED TO THE BIN.



RELAY SUPPLY IN THE SYSTEM IN THE MANUAL SUPERVISOR UNIT

DESCRIPTION

THIS MODULE PROVIDES A SET OF 5 ALARM CONTACTS. IT IS OF THE PORTABLE AND MOUNTABLE FOR CONNECTIONS. THE MODULE IS SUPPLIED WITH A RESISTIVE OR 2 WIRE TERMINALS AT 20 V.D.C. OR 120 V.A.C. OR ALARM ON THE FIRE ALARM SYSTEM WILL CAUSE THE ALARM CONTACTS ON THE MODULE TO TRIP. THIS WILL SEND IN A SIGNAL TO THE MUNICIPAL BOX, DRAWING IN TO OPEN THE CODE TO THE "D" OR "N" SIGNAL STATION.

THE PULLER MUST BE REMOVED FROM THE MODULE. THE MUNICIPAL BOX HAS TWO (2) CONTACTS WHICH OPERATE AT THE JUNCTION OF THE TRIP, THESE SHOULD BE WELDED INTO A TRIP ALARM DETECTING CIRCUIT TO BE CONNECTED TO A MANUAL STATION ALARM. IT IS RECOMMENDED THAT OPERATION OF THE MANUAL BOX SHOULD CAUSE THE LOCAL FIRE ALARM SIGNALS TO SOUND.

THE CONNECTIONS OF THE ALARM MUST BE COMPLETED BY THE INSTALLATION PERSONNEL SWITCH LOCATED ON THE COMMON CONTROL BIN ASSEMBLY UNIT. ALL THE WIRING ARE PROVIDED WITH IS TERMINAL OR THE PULLER DETACHABLE FROM THE PULLER. IT IS RECOMMENDED THAT THE PULLER IS REMOVED FROM THE PULLER. IT IS RECOMMENDED THAT THE PULLER IS REMOVED FROM THE PULLER. IT IS RECOMMENDED THAT THE PULLER IS REMOVED FROM THE PULLER.


A DETAILED SYSTEM OF ALARM, COMMON CONTROL, ALARMS AND PULLER PLACEMENT IN DRAWING, REFER TO THE DRAWING AND OPERATION MANUAL FOR ADDITIONAL INFORMATION.

INSTALLATION

THE ALARM SYSTEM COMPONENTS SHOULD BE INSTALLED IN ACCORDANCE WITH THE LATEST ISSUE OF THE NATIONAL FIRE ALARM CODE, ARTICLE 750.


MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	
MUNICIPAL TIE MODULE	

45003-0778
 10/1/78
 10/1/78



RELAYS ARE CONNECTED TO A TRAILING CONTACT OF A RELAY AT STATION 10000. THE RELAY IS OPERATED BY THE STATION RELAY. THE RELAY IS OPERATED BY THE STATION RELAY.

NOTE: THIS RELAY IS CONNECTED TO A TRAILING CONTACT OF A RELAY AT STATION 10000. THE RELAY IS OPERATED BY THE STATION RELAY. THE RELAY IS OPERATED BY THE STATION RELAY.



RELAYS SHOWN WITH 100 OHM IN THE NORMAL UNASSIGNED POS. THROUGH CONTACTS ENERGIZED

MOUNTING

THE CAN A PINE B-43 REVERSE POLARITY MODULE PLUGS INTO THE TERMINAL CONTACT PLUGS MOUNTED ON THE ASSIGNED PIN AS SHOWN BELOW. THE CAN A PINE B-43 MUST BE USED WITH A 2 AMP FUSE PLUGGED BEHIND THE TERMINAL CONTACT ON THE BATTERY BOARD. THE FUSE MUST BE PLUGGED BEHIND THE TWO REVERSE POLARITY MODULES. THE CAN A PINE B-43 MUST BE PLUGGED INTO THE TWO SCREW TERMINALS AS SHOWN BELOW.




FIGURE 10-10 REVERSE POLARITY MODULE CONTROL BOARD

DESCRIPTION

EACH MODULE PROVIDES 100 OHM REVERSE POLARITY CONTACTS. THE CAN A PINE B-43 REVERSE POLARITY MODULES ARE PLUGGED INTO THE TWO SCREW TERMINALS AS SHOWN BELOW. THE CAN A PINE B-43 MUST BE PLUGGED INTO THE TWO SCREW TERMINALS AS SHOWN BELOW.

THE TRANSMISSION OF A SIGNAL MAY BE INITIATED BY THE CAN A PINE B-43 REVERSE POLARITY MODULE LOCATED IN THE SIGNAL CONTROL BOARD. THE CAN A PINE B-43 REVERSE POLARITY MODULE PLUGS INTO THE TERMINAL CONTACT PLUGS MOUNTED ON THE ASSIGNED PIN AS SHOWN BELOW.


THE CAN A PINE B-43 REVERSE POLARITY MODULE PLUGS INTO THE TERMINAL CONTACT PLUGS MOUNTED ON THE ASSIGNED PIN AS SHOWN BELOW. THE CAN A PINE B-43 MUST BE PLUGGED INTO THE TWO SCREW TERMINALS AS SHOWN BELOW.

THE CAN A PINE B-43 REVERSE POLARITY MODULE PLUGS INTO THE TERMINAL CONTACT PLUGS MOUNTED ON THE ASSIGNED PIN AS SHOWN BELOW. THE CAN A PINE B-43 MUST BE PLUGGED INTO THE TWO SCREW TERMINALS AS SHOWN BELOW.

THE CAN A PINE B-43 REVERSE POLARITY MODULE PLUGS INTO THE TERMINAL CONTACT PLUGS MOUNTED ON THE ASSIGNED PIN AS SHOWN BELOW. THE CAN A PINE B-43 MUST BE PLUGGED INTO THE TWO SCREW TERMINALS AS SHOWN BELOW.


THE CAN A PINE B-43 REVERSE POLARITY MODULE PLUGS INTO THE TERMINAL CONTACT PLUGS MOUNTED ON THE ASSIGNED PIN AS SHOWN BELOW. THE CAN A PINE B-43 MUST BE PLUGGED INTO THE TWO SCREW TERMINALS AS SHOWN BELOW.

THE CAN A PINE B-43 REVERSE POLARITY MODULE PLUGS INTO THE TERMINAL CONTACT PLUGS MOUNTED ON THE ASSIGNED PIN AS SHOWN BELOW. THE CAN A PINE B-43 MUST BE PLUGGED INTO THE TWO SCREW TERMINALS AS SHOWN BELOW.



MOUNTING

THE CAT. # 68002-0553 AUXILIARY POWER MODULE PLUGS INTO THE COMMON CONTROL OR EXPANDED CONTROL BUS ASSEMBLY AS SHOWN IN FIG. 3. THE ZERO OHM RESISTOR (ZERO OHM) IS A 0.000 OHM, LOCATED BETWEEN THE CONNECTOR PLUG ON THE BUS CIRCUIT BOARD AND THE MODULE BEFORE THE MODULE IS PLUGGED INTO THE COMMON CONTROL BOARD. THE COMMON CONTROL BOARD AND THE ZERO OHM RESISTOR MUST BE REMOVED BEFORE THE MODULE IS PLUGGED INTO THE COMMON CONTROL BOARD. THE COMMON CONTROL BOARD IS PLUGGED INTO THE COMMON CONTROL BOARD.




DESCRIPTION

EACH MODULE PROVIDES 1 AMPERE FOR THE D.C. SOURCE. RESISTANCE 24 V.D.C./EARTH FILTERED. THIS IS PACKAGED WITH 48 BRICKS OR (MOUNTS) IS AVAILABLE FROM THE MANUFACTURER. NON-REVERSIBLE 24 V.D.C./EARTH, 0.000 OHM, IS BATTERY BACKED WITH 48 BRICKS OR (MOUNTS). THIS MODULE FROM TERMINALS 13 AND 14, WHICH IS AN ASSEMBLY WITH A MAXIMUM OF 4.0 A. IS BATTERY BACKED AND UNFILTERED AUXILIARY CURRENT.

FOR THE SYSTEM OPERATION, CHECK CONTROL PANELS AND MODULE PLACEMENT INFORMATION REFER TO THE INSTALLATION IN OPERATION MANUAL FOR 68002-0553.


INSTALLATION

EACH AUXILIARY POWER MODULE SHOULD BE INSTALLED IN ACCORDANCE WITH THE LATEST ISSUES OF THE NATIONAL ELECTRICAL CODE, ARTICLE 705.




DATE	
DRAWN BY	
CHECKED BY	
DESIGNED BY	
APPROVED BY	
HUMPHRIES & BOND	
CUSTOMER DRINKING WATER	
CAT. 6802-0553	
AUXILIARY POWER MODULE	
DATE	2003-08-01
REV	1
DESCRIPTION	REVISION
NO. OF SHEETS	1
TOTAL NO. OF SHEETS	1
PROJECT NO.	40001-0000
SCALE	

48000-CAT1A
 10/80
 10/80



CAT. 0000-0000
 IN THE OPERATOR CAN TYPED IN
 ON THE TERMINAL UNIT AND
 AND TYPED IN




TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

NOTE: NO OPERATOR CAN TYPED IN
 ON THE TERMINAL UNIT AND
 AND TYPED IN

10/80
 10/80
 10/80

10/80
 10/80
 10/80



CAT. 0000-0000
 IN THE OPERATOR CAN TYPED IN
 ON THE TERMINAL UNIT AND
 AND TYPED IN

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

10/80
 10/80
 10/80

10/80
 10/80
 10/80

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR




1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	78	79	80
81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR

TO BE USED AS A CHECK
 POINT FOR THE
 OPERATOR



FRONT VIEW
6816-8504 WITH 6 WALLBOX ASSEMBLY

SURFACE
REF. AREA WITH
1/8" x 1/8"

DESCRIPTION

THE CABINET 6816-8504 DIFF AND WALLBOX ASSEMBLY PROVIDES WALL MOUNTED BELL AND BATTERY MONITORING SIGNALS CENTER/ARMED SIGNALS SEPARATELY AND A 5 AMP BATTERY, ONE 3" DEEP WALLBOX MAY BE SURFACE OR FLUSH MOUNTED. WHEN 5.1 AMP RELAYING IS SUPPLIED, OPTIONAL CENTER ARMED SIGNAL IS REQUIRED. THE 1/2" DEEP WALLBOX MOUNTING THE DIFF TO THE WALLBOX IS SUPPLIED WITH THE CAB. 6816-8504/8504 BATTERY MONITORING SIGNALS SEPARATELY. MOUNT DIFF WITH THE BOX ASSEMBLY TAB WHEN INSTALLED. CORRECT DIMENSION STRAP FROM COVER WALLBOX WITH CABLE PROVIDED 1 1/4 BMS SEPARATELY.

FOR DETAILED SYSTEM OPERATION, COMMON CONTROL, SIGNALS AND HOLES PLEASE REFER TO INFORMATION. REFER TO THE INSTALLATION AND OPERATION MANUAL TO 48000-0779.

MATERIALS - WELD POLISHED STEEL


- FINISH - MILD STEEL POLISHED WITH SINGLE FINISH
- DOOR - BRASS 3/4" HEAVY FLEXIBLES VORONA
- WORKINGS - DATA BOOK

INSTALLATION

FIRE ALARM SYSTEM COMPONENTS SHOULD BE INSTALLED TO COMPLIANCE WITH THE LATEST EDITIONS OF THE NATIONAL ELECTRICAL CODE AND NFPA 720.

6816-8504 OR BEIG-BEIG DIMENSION CONTAINS BMS SEPARATELY FOR MANUAL SUPPLY, WALLBOX ASSEMBLY FOR SIGNALS CIRCUIT AND OPERATOR CONTROL.


FRONT BATTERY AND DIFF WITH CHARGER



JOINT VIEW
WITH TUB REMOVED

1. KNOCKOUT IN BOTH SIDES FOR CHARGER MOUNTING

1/2-1/2" KNOCKOUT ON TOP FOR BATTERY MOUNTING



KNOCKOUT LOCATIONS

REV. NO.	DATE	BY	DESCRIPTION
1	10/80	EDWARDS	ISSUE



DATE	10/80
REV. NO.	1
BY	EDWARDS
CHECKED BY	
APPROVED BY	
EDWARDS	
CUSTOMER DRAWING	
CAT. 6816-8504	
DOOR AND WALLBOX ASSEMBLY	

FOR READING OF THIS MANUAL IN THE FUTURE, REFER TO THE TYPING MACHINE.

ONE POSITION (U/M - HOLD)


CURTAIN
TRIPPER PULSE

THIS POSITION (U/M - HOLD) IS USED TO SERVICE AN INDIVIDUAL TRIGGER UNIT (IF REQUIRED)



6616-0107 (POWER SUPPLY AND BATTERY CHARGER)

COMMON CONTROL FRONT PANEL 0018-0902



- 1. POWER ON
- 2. POWER OFF
- 3. CURTAIN TRIPPER
- 4. CURTAIN TRIPPER
- 5. CURTAIN TRIPPER
- 6. CURTAIN TRIPPER
- 7. CURTAIN TRIPPER
- 8. CURTAIN TRIPPER
- 9. CURTAIN TRIPPER

- 10. CURTAIN TRIPPER
- 11. CURTAIN TRIPPER

DESCRIPTION

The unit contains power control and alarm system which provides the control for the alarm system. It is used to control the alarm system and to provide the power to the alarm system.

- Alarm system which provides power to the alarm system.
- Power control system which provides power to the alarm system.
- Alarm system which provides power to the alarm system.
- Power control system which provides power to the alarm system.

The unit is used to control the alarm system and to provide the power to the alarm system. It is used to control the alarm system and to provide the power to the alarm system.

INSTALLATION

The unit should be installed in a dry location. It should be installed in a dry location. It should be installed in a dry location.

CAUTION

DO NOT INSERT MODULES WITH THE POWER ON!

CUSTOMER DRAWING PART: 6616-0802 COMMON CONTROL/PAH SUPPLY	
DATE	REV.
08/03/00	1
08/03/00	2
08/03/00	3
08/03/00	4
08/03/00	5
08/03/00	6
08/03/00	7
08/03/00	8
08/03/00	9
08/03/00	10
08/03/00	11
08/03/00	12
08/03/00	13
08/03/00	14
08/03/00	15
08/03/00	16
08/03/00	17
08/03/00	18
08/03/00	19
08/03/00	20
08/03/00	21
08/03/00	22
08/03/00	23
08/03/00	24
08/03/00	25
08/03/00	26
08/03/00	27
08/03/00	28
08/03/00	29
08/03/00	30
08/03/00	31
08/03/00	32
08/03/00	33
08/03/00	34
08/03/00	35
08/03/00	36
08/03/00	37
08/03/00	38
08/03/00	39
08/03/00	40
08/03/00	41
08/03/00	42
08/03/00	43
08/03/00	44
08/03/00	45
08/03/00	46
08/03/00	47
08/03/00	48
08/03/00	49
08/03/00	50


68100-0082
REV. 10-80

FOR PARTS LIST SEE
PAGE 11 OF THIS DRAWING
OR SEE DRAWING 68100-0082

SPACE FOR SIGNAL BATT-TH KNOBS

RECALL
DEVICE PANEL


FOR EXT. BATTERY CONTROL
MODULES TO INST. & ADMIN. PANEL OR
TROUBLE UNIT (IF PROVIDED)



FOR EXT. BATTERY
CONTROL MODULES
TO INST. & ADMIN.
PANEL OR TROUBLE
UNIT (IF PROVIDED)

FOR EXT. BATTERY
CONTROL MODULES
TO INST. & ADMIN.
PANEL OR TROUBLE
UNIT (IF PROVIDED)

COMMON RING RING FRONT PANEL 6810-0204



- 1. SIGNAL 1
- 2. SIGNAL 2
- 3. SIGNAL 3
- 4. SIGNAL 4
- 5. SIGNAL 5
- 6. SIGNAL 6
- 7. SIGNAL 7
- 8. SIGNAL 8
- 9. SIGNAL 9
- 10. SIGNAL 10
- 11. SIGNAL 11
- 12. SIGNAL 12

DESCRIPTION

TO BE USED WITH THE CONTROL UNIT AND TO BE USED WITH THE CONTROL UNIT AND TO BE USED WITH THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT.

THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT.

INSTALLATION

THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT. THE CONTROL UNIT IS USED TO CONTROL THE CONTROL UNIT.

CAUTION

DO NOT INSERT MODULES WITH THE POWER ON!

WARNING

THIS UNIT OPERATES ON 120V AC. ALWAYS VERIFY THE VOLTAGE BEFORE WORKING ON THE UNIT. ALWAYS USE THE PROPER SAFETY PROCEDURES WHEN WORKING ON ELECTRICAL EQUIPMENT. ALWAYS USE THE PROPER SAFETY PROCEDURES WHEN WORKING ON ELECTRICAL EQUIPMENT.

- 1. SIGNAL 1
- 2. SIGNAL 2
- 3. SIGNAL 3
- 4. SIGNAL 4
- 5. SIGNAL 5
- 6. SIGNAL 6
- 7. SIGNAL 7
- 8. SIGNAL 8
- 9. SIGNAL 9
- 10. SIGNAL 10
- 11. SIGNAL 11
- 12. SIGNAL 12

1	2	3	4	5	6	7	8	9	10	11	12
CUSTOMER DRIVING CAT. 6635-0074 COMMON CONTROL UNIT SUPPLY											
EDWARDS 1000 S. W. 10TH ST. MIAMI, FL 33135											

48000-57/82
REV. 10/82

DESCRIPTION


THE 604 FIRE ALARM CONTROL PANEL IS A CONTROL UNIT FOR SINGLE STAGE CONTROL OF FIRE ALARM INDICATORS. IT MAY BE INSTALLED IN EITHER ST. 0 OR ST. 1 AND MAY BE CONTROLLED BY EITHER ST. 0 OR ST. 1. THE ST. 0 AND ST. 1 SIGNALS ARE PROVIDED BY THE FIRE ALARM CONTROL PANEL. THE ST. 0 AND ST. 1 SIGNALS ARE PROVIDED BY THE FIRE ALARM CONTROL PANEL. THE ST. 0 AND ST. 1 SIGNALS ARE PROVIDED BY THE FIRE ALARM CONTROL PANEL.

INSTALLATION

THE 604 FIRE ALARM CONTROL PANEL SHOULD BE INSTALLED IN A CLEAN, DRY, WELL-VENTILATED AREA. IT SHOULD BE PROTECTED FROM EXCESSIVE HEAT AND MOISTURE. THE PANEL SHOULD BE INSTALLED ON A NON-FLAMMABLE SURFACE. THE PANEL SHOULD BE PROTECTED FROM EXCESSIVE HEAT AND MOISTURE. THE PANEL SHOULD BE INSTALLED ON A NON-FLAMMABLE SURFACE.

CAUTION

DO NOT INSERT MODULES WITH THE POWER ON. ALWAYS DISCONNECT THE MAINLINE POWER BEFORE ATTEMPTING TO INSERT OR REMOVE MODULES.




FORWARDING INFORMATION
 CUSTOMER INSTALLATION ORDER
 CAT. 5636
 FIRE ALARM CONTROL PANEL

DATE	BY	REV.	APPROVAL
10/82	J.E.	1	

FIG. 1
 MODEL 6720
 12 VDC
 1.2 A

TRAP-1001 DOOR & HALLBOX ASSEMBLY



SURFACE

STUD LOCATION FOR DOOR/ HALLBOX BRACKETS

FLASH

BEZE-1001 WITH 22 1/2" x 36 1/2"

INSTALLATION

FIRE ALARM SYSTEM COMPONENTS SHOULD BE INSTALLED IN ACCORDANCE WITH THE LATEST EDITION OF THE NATIONAL FIRE PROTECTION ASSOCIATION (NFPA) 720, FIRE ALARM CODE.

MATERIAL - GILD ROLLED STEEL

- FINISH - HALLBOX AND FLASH TRIM : BRASS TAN
- DOOR : BEZE-1001 BRASS FLEXIGLAS WINDOW
- MARKINGS : DARK BRONZE

DESCRIPTION

THE CAT. # 6720 DOOR AND HALLBOX ASSEMBLY PROVIDES SPACE FOR A GILD-ROLED STEEL COMMON CONTROL BELL-ASSEMBLY, A BEZE-1001/BEZE-1004 EX-1001 CONTROL POWER SUPPLY ASSEMBLY AND TWO BATTERY BATTERIES. THE TRAP-1001 ASSEMBLY MAY BE SURMOUNTED WITH EITHER A BELL-ASSEMBLY OR A BELL-ASSEMBLY WITH TWO BATTERIES. THE BELL-ASSEMBLY WITH TWO BATTERIES IS REQUIRED. THE HALLBOX ASSEMBLY FOR THE TRAP-1001 IS SUPPLIED TO THE HALLBOX ASSEMBLY WITH THE CAT. # BELG-BEZE/EXPANDED HALLBOX/POWER SUPPLY ASSEMBLY. BOTH BEZE-1001 AND BEZE-1004 HALLBOXES HAVE BEEN INSTALLED. CONTACT HALLBOX FROM DOOR TO HALLBOX WITH CABLE PROVIDED IN BAG ASSEMBLY.


FOR DETAILS ON SYSTEM OPERATION, COMMON CONTROL TERMINALS AND MODULES REFER TO THE INSTALLATION AND OPERATION MANUAL # 45000-0755.

BEZE-1001 OR BEZE-1004 COMMON CONTROL WITH ASSEMBLY CAN POWER SUPPLY AND BATTERIES FOR IS TRIM CONTROL

BEZE-1001 OR BEZE-1004 EXPANDED HALLBOX ASSEMBLY CAN POWER SUPPLY AND BATTERIES FOR IS TRIM CONTROL

BEZE-1001 AND BEZE-1004 EXPANDED HALLBOX ASSEMBLY

FRONT VIEW WITH DOOR REMOVED



KNOCKOUT LOCATIONS

FIG. 1

NO. OF SHEETS	1
TOTAL NO. OF SHEETS	1
NO. OF SHEETS USED	1
NO. OF SHEETS LEFT	0

REV	DATE	BY	CHKD	DESCRIPTION

THE TRAP-1001
EDWARDS
 CUSTOMER DRAWING
 CAT. 6720-1001
 COPY # HALLBOX ASSEMBLY


NO. OF SHEETS USED: 1
 TOTAL NO. OF SHEETS: 1
 NO. OF SHEETS LEFT: 0
 NO. OF SHEETS USED: 1

FIG. 1
 MODEL 6720
 12 VDC
 1.2 A

6800L-0880
681000-0000

-IF IN THE BOX OF THE 6802-900 IN ORDER TO MAKE THE 6802-900

POINTS FOR THE PULL-IN COILS TO 500 OHM RESISTANCE COMMON FOR THE



6802-900

DESCRIPTION

The 6802-900, 6802-901, 6802-902, 6802-903, 6802-904, 6802-905, 6802-906, 6802-907, 6802-908, 6802-909, 6802-910, 6802-911, 6802-912, 6802-913, 6802-914, 6802-915, 6802-916, 6802-917, 6802-918, 6802-919, 6802-920, 6802-921, 6802-922, 6802-923, 6802-924, 6802-925, 6802-926, 6802-927, 6802-928, 6802-929, 6802-930, 6802-931, 6802-932, 6802-933, 6802-934, 6802-935, 6802-936, 6802-937, 6802-938, 6802-939, 6802-940, 6802-941, 6802-942, 6802-943, 6802-944, 6802-945, 6802-946, 6802-947, 6802-948, 6802-949, 6802-950, 6802-951, 6802-952, 6802-953, 6802-954, 6802-955, 6802-956, 6802-957, 6802-958, 6802-959, 6802-960, 6802-961, 6802-962, 6802-963, 6802-964, 6802-965, 6802-966, 6802-967, 6802-968, 6802-969, 6802-970, 6802-971, 6802-972, 6802-973, 6802-974, 6802-975, 6802-976, 6802-977, 6802-978, 6802-979, 6802-980, 6802-981, 6802-982, 6802-983, 6802-984, 6802-985, 6802-986, 6802-987, 6802-988, 6802-989, 6802-990, 6802-991, 6802-992, 6802-993, 6802-994, 6802-995, 6802-996, 6802-997, 6802-998, 6802-999, 6802-1000.

- THE 6802-900, 6802-901, 6802-902, 6802-903, 6802-904, 6802-905, 6802-906, 6802-907, 6802-908, 6802-909, 6802-910, 6802-911, 6802-912, 6802-913, 6802-914, 6802-915, 6802-916, 6802-917, 6802-918, 6802-919, 6802-920, 6802-921, 6802-922, 6802-923, 6802-924, 6802-925, 6802-926, 6802-927, 6802-928, 6802-929, 6802-930, 6802-931, 6802-932, 6802-933, 6802-934, 6802-935, 6802-936, 6802-937, 6802-938, 6802-939, 6802-940, 6802-941, 6802-942, 6802-943, 6802-944, 6802-945, 6802-946, 6802-947, 6802-948, 6802-949, 6802-950, 6802-951, 6802-952, 6802-953, 6802-954, 6802-955, 6802-956, 6802-957, 6802-958, 6802-959, 6802-960, 6802-961, 6802-962, 6802-963, 6802-964, 6802-965, 6802-966, 6802-967, 6802-968, 6802-969, 6802-970, 6802-971, 6802-972, 6802-973, 6802-974, 6802-975, 6802-976, 6802-977, 6802-978, 6802-979, 6802-980, 6802-981, 6802-982, 6802-983, 6802-984, 6802-985, 6802-986, 6802-987, 6802-988, 6802-989, 6802-990, 6802-991, 6802-992, 6802-993, 6802-994, 6802-995, 6802-996, 6802-997, 6802-998, 6802-999, 6802-1000.

The 6802-900, 6802-901, 6802-902, 6802-903, 6802-904, 6802-905, 6802-906, 6802-907, 6802-908, 6802-909, 6802-910, 6802-911, 6802-912, 6802-913, 6802-914, 6802-915, 6802-916, 6802-917, 6802-918, 6802-919, 6802-920, 6802-921, 6802-922, 6802-923, 6802-924, 6802-925, 6802-926, 6802-927, 6802-928, 6802-929, 6802-930, 6802-931, 6802-932, 6802-933, 6802-934, 6802-935, 6802-936, 6802-937, 6802-938, 6802-939, 6802-940, 6802-941, 6802-942, 6802-943, 6802-944, 6802-945, 6802-946, 6802-947, 6802-948, 6802-949, 6802-950, 6802-951, 6802-952, 6802-953, 6802-954, 6802-955, 6802-956, 6802-957, 6802-958, 6802-959, 6802-960, 6802-961, 6802-962, 6802-963, 6802-964, 6802-965, 6802-966, 6802-967, 6802-968, 6802-969, 6802-970, 6802-971, 6802-972, 6802-973, 6802-974, 6802-975, 6802-976, 6802-977, 6802-978, 6802-979, 6802-980, 6802-981, 6802-982, 6802-983, 6802-984, 6802-985, 6802-986, 6802-987, 6802-988, 6802-989, 6802-990, 6802-991, 6802-992, 6802-993, 6802-994, 6802-995, 6802-996, 6802-997, 6802-998, 6802-999, 6802-1000.

FOR DETAILS ON THE 6802-900, 6802-901, 6802-902, 6802-903, 6802-904, 6802-905, 6802-906, 6802-907, 6802-908, 6802-909, 6802-910, 6802-911, 6802-912, 6802-913, 6802-914, 6802-915, 6802-916, 6802-917, 6802-918, 6802-919, 6802-920, 6802-921, 6802-922, 6802-923, 6802-924, 6802-925, 6802-926, 6802-927, 6802-928, 6802-929, 6802-930, 6802-931, 6802-932, 6802-933, 6802-934, 6802-935, 6802-936, 6802-937, 6802-938, 6802-939, 6802-940, 6802-941, 6802-942, 6802-943, 6802-944, 6802-945, 6802-946, 6802-947, 6802-948, 6802-949, 6802-950, 6802-951, 6802-952, 6802-953, 6802-954, 6802-955, 6802-956, 6802-957, 6802-958, 6802-959, 6802-960, 6802-961, 6802-962, 6802-963, 6802-964, 6802-965, 6802-966, 6802-967, 6802-968, 6802-969, 6802-970, 6802-971, 6802-972, 6802-973, 6802-974, 6802-975, 6802-976, 6802-977, 6802-978, 6802-979, 6802-980, 6802-981, 6802-982, 6802-983, 6802-984, 6802-985, 6802-986, 6802-987, 6802-988, 6802-989, 6802-990, 6802-991, 6802-992, 6802-993, 6802-994, 6802-995, 6802-996, 6802-997, 6802-998, 6802-999, 6802-1000.


INSTALLATION

FOR DETAILS ON THE 6802-900, 6802-901, 6802-902, 6802-903, 6802-904, 6802-905, 6802-906, 6802-907, 6802-908, 6802-909, 6802-910, 6802-911, 6802-912, 6802-913, 6802-914, 6802-915, 6802-916, 6802-917, 6802-918, 6802-919, 6802-920, 6802-921, 6802-922, 6802-923, 6802-924, 6802-925, 6802-926, 6802-927, 6802-928, 6802-929, 6802-930, 6802-931, 6802-932, 6802-933, 6802-934, 6802-935, 6802-936, 6802-937, 6802-938, 6802-939, 6802-940, 6802-941, 6802-942, 6802-943, 6802-944, 6802-945, 6802-946, 6802-947, 6802-948, 6802-949, 6802-950, 6802-951, 6802-952, 6802-953, 6802-954, 6802-955, 6802-956, 6802-957, 6802-958, 6802-959, 6802-960, 6802-961, 6802-962, 6802-963, 6802-964, 6802-965, 6802-966, 6802-967, 6802-968, 6802-969, 6802-970, 6802-971, 6802-972, 6802-973, 6802-974, 6802-975, 6802-976, 6802-977, 6802-978, 6802-979, 6802-980, 6802-981, 6802-982, 6802-983, 6802-984, 6802-985, 6802-986, 6802-987, 6802-988, 6802-989, 6802-990, 6802-991, 6802-992, 6802-993, 6802-994, 6802-995, 6802-996, 6802-997, 6802-998, 6802-999, 6802-1000.


CAUTION

DO NOT INSERT MODULES WITH THE POWER ON !

COMMON/EXPANDER CONTROL VONHEINGANG



EXPANDER CONTROL FRONT PANEL 8802 8802




EXPANDER CONTROL FRONT PANEL 8802 8802			
NO.	1	2	3
TYPE	1	2	3
MARKING	1	2	3
DATE	1	2	3
BY	1	2	3
REVISION	1	2	3
MILITARY			
EDWARDS			
CUSTOMER DRAWING			
CAT. 6802-8802			
EXPANDER CONTROL FRONT PANEL SUPPLY			
NO.	1	2	3
TYPE	1	2	3
MARKING	1	2	3
DATE	1	2	3
BY	1	2	3
REVISION	1	2	3

REF ID: A6000-1038
REV. 10/87

WITH QUANTITY RITLES PROVIDED IN THE BACK OF THE 8832-8802 RAILBOX.

THIS IS A 715 VOLT SHIELDED CABLE

TO FID ON 8832-8804 COMMON CONTROL MULTIMANU



DESCRIPTION

The 8816-8804 Common Control and Power Supply includes three 8816-A102 power supplies, two 8842E-8842B batteries, a transformer, and a common control unit. The 8816-A102 power supplies are used to provide power to the common control unit. The 8842E-8842B batteries are used to provide backup power to the common control unit. The transformer is used to provide power to the common control unit. The common control unit is used to provide power to the common control unit.

When components are removed from the rack, remove the common control unit from the rack. The common control unit is used to provide power to the common control unit. The common control unit is used to provide power to the common control unit. The common control unit is used to provide power to the common control unit. The common control unit is used to provide power to the common control unit.

See the rack and system operation manual for more information on the installation and operation of the 8816-8804 Common Control and Power Supply.


INSTALLATION

For alarm system operation, connect the common control unit to the rack. The common control unit is used to provide power to the common control unit. The common control unit is used to provide power to the common control unit. The common control unit is used to provide power to the common control unit.


CAUTION

DO NOT INSERT MODULES WITH THE POWER ON!

COMMON/EXPANDER CONTROL NOTIFICATION



EXPANDER CONTROL FRONT PANEL 8832-8804



WARNING

THIS UNIT OPERATES ON 115V AC. THE POWER SUPPLY SHOULD BE CHECKED TO BE SURE IT IS SET TO 115V AC. THE POWER SUPPLY SHOULD BE CHECKED TO BE SURE IT IS SET TO 115V AC. THE POWER SUPPLY SHOULD BE CHECKED TO BE SURE IT IS SET TO 115V AC.

1	2	3	4	5	6	7	8

EDWARDS

CUSTOMER TRAINING
P.O. BOX 8804
EXPANDER CONTROL/POWER SUPPLY

REF ID: A6000-1038
REV. 10/87

DEVICE COMPATIBILITY CHART

COMPATIBILITY INFORMATION FOR EDWARDS
6616 AND 6632
FIRE ALARM CONTROL PANELS
C.I.# 661602

NOTE: All catalog numbers are Edwards unless otherwise indicated

INITIATING DEVICES

Non-Coded Manual Stations

Cat. No. 270-SPC, 270-DPO, 270A-SPO, 270A-DPO, 275B, 277B, 278B, 279B

Waterflow Alarm Switches

WFS Series (Potter Electric)

Heat Detectors

Fixed Temperature / Rate-of-Rise - Cat. No. 281B, 282B, 291B*, 292B*

Fixed Temperature - Cat. No. 283B, 284B, 445, 44R, 293B*, 294B*

Open Area Smoke Detectors (Two Wire Configurations) C.I. # 001

Ionization - Cat. No. 6240B, 6250B*

Photoelectric - Cat. No. 6269B, 6266B-003, 6270B*, 6270B-003*

*For use with following bases: Cat. No. 6251B-001 (6250B remote LED capability),
6251B-003 (auxiliary relay).

Duct Type Smoke Detectors (Two Wire Configurations) C.I. # 001

Ionization - Cat. No. 6264B **

Photoelectric - Cat. No. 6266B **

**For use with following duct detector housings: Cat. No. 6260B, 6266B-001 (includes 6262B-001 test station), 6265B-002 (includes 6262B-001 test station and 6254B-003 relay unit)

- Notes: (1) Maximum number of ionization detectors is 50.
(2) Maximum number of photo electric detectors is 30.
(3) If detectors with relay bases are required, only one detector with a relay base should be installed on a circuit, to ensure the activation of the ancillary device connected to the base relay.

SIGNALING DEVICES

Cat. No.	Bells	Horns		
			Other	Strobes
	439B-(*)AW	892-10, 892-25		
	<u>Horn/Strobe Units</u>			
Cat. No.	092-1B 802-2D 802-6D	5530D-AW Duotronic Horn/Siren, 5530D-AW /Adaptatone Electronic Signal 128D-024 Signal (Piezoelectric Type) 692-1B Signal (Piezoelectric Type) 692-2B, 692-0B Signal/Strobe		202-2B 202-6B 894B-001 902-2B 902-6B

* Bells available with 6, 8 or 10 inch gongs.